


User's Manual

HIPOT Tester

19071/19072/19073



Get more product & global distributor information in Chroma ATE APP



HIPOT Tester 19071/19072/19073 User's Manual



Version 3.5
June 2024

Legal Notices

The information in this document is subject to change without notice.

Chroma ATE INC. makes no warranty of any kind with regard to this manual, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Chroma ATE INC. shall not be held liable for errors contained herein or direct, indirect, special, incidental, or consequential damages in connection with the furnishing, performance, or use of this material.

CHROMA ATE INC.

88 Wenmao Rd., Guishan Dist., Taoyuan City 333001, Taiwan

Copyright Notices. Copyright 2003 Chroma ATE INC., all rights reserved. Reproduction, adaptation, or translation of this document without prior written permission is prohibited, except as allowed under the copyright laws.

All other brand and product names are trademarks or registered trademarks of their respective holders.

Warranty

All of Chroma's instruments are warranted against defects in material and workmanship for a period of one year from the date of shipment. Chroma agrees to repair or replace any assembly or component found to be defective, under normal use during this period.

Chroma's obligation under this warranty is limited solely to repairing any such instrument, which in Chroma's sole opinion proves to be defective within the scope of the warranty when returned to the factory or to an authorized service center. Purchaser is responsible for the shipping and cost of the service item to Chroma factory or service center. Shipment should not be made without prior authorization by Chroma.

This warranty does not apply to any products repaired or altered by persons not authorized by Chroma, or not in accordance with instructions furnished by Chroma. If the instrument is defective as a result of misuse, improper repair, or abnormal conditions or operations, repairs will be billed at cost.

Chroma assumes no responsibility for its product being used in a hazardous or dangerous manner either alone or in conjunction with other equipment. High voltage used in some instruments may be dangerous if misused. Special disclaimers apply to these instruments. Chroma assumes no liability for secondary charges or consequential damages and in any event, Chroma's liability for breach of warranty under any contract or otherwise, shall not exceed the purchase price of the specific instrument shipped and against which a claim is made.

Any recommendations made by Chroma regarding the use of its products are based upon tests believed to be reliable; Chroma makes no warranty of the results to be obtained. This warranty is in lieu of all other warranties, expressed or implied, and no representative or person is authorized to represent or assume for Chroma any liability in connection with the sale of our products other than set forth herein.

Chroma undertakes no liability for any special or consequential damages, or any of our customer's compensation responsibilities to third parties, arising from use or access of our product.

CHROMA ATE INC.

88 Wenmao Rd., Guishan Dist.

Taoyuan City 333001, Taiwan

Tel: 886-3-327-9999


Fax: 886-3-327-8898

e-mail: info@chromaate.com

www.chromaate.com

Material Contents Declaration

The recycling label shown on the product indicates the Hazardous Substances contained in the product as the table listed below.



<Table 1>

Part Name	Hazardous Substances					
	Lead	Mercury	Cadmium	Hexavalent Chromium	Polybrominated Biphenyls/ Polybromodiphenyl Ethers	Selected Phthalates Group
	Pb	Hg	Cd	Cr ⁶⁺	PBB/PBDE	DEHP/BBP/DBP/DIBP
PCBA	O	O	O	O	O	O
CHASSIS	O	O	O	O	O	O
ACCESSORY	O	O	O	O	O	O
PACKAGE	O	O	O	O	O	O

“O” indicates that the level of the specified chemical substance is less than the threshold level specified in the standards of SJ/T-11363-2006, EU Directive 2011/65/EU, and 2015/863/EU.

“×” indicates that the level of the specified chemical substance exceeds the threshold level specified in the standards of SJ/T-11363-2006, EU Directive 2011/65/EU, and 2015/863/EU.

Remarks:

1. The CE marking on the product is a declaration of product compliance with EU Directive 2011/65/EU and 2015/863/EU.
2. This product complies with EU REACH regulations and no SVHC is in use.

Disposal

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being. When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliances for disposal at least free of charge.



<Table 2>

Part Name	Hazardous Substances					
	Lead	Mercury	Cadmium	Hexavalent Chromium	Polybrominated Biphenyls/ Polybromodiphenyl Ethers	Selected Phthalates Group
	Pb	Hg	Cd	Cr ⁶⁺	PBB/PBDE	DEHP/BBP/DBP/DIBP
PCBA	×	○	○	○	○	○
CHASSIS	×	○	○	○	○	○
ACCESSORY	×	○	○	○	○	○
PACKAGE	○	○	○	○	○	○

“○” indicates that the level of the specified chemical substance is less than the threshold level specified in the standards of SJ/T-11363-2006, EU Directive 2011/65/EU, and 2015/863/EU.

“×” indicates that the level of the specified chemical substance exceeds the threshold level specified in the standards of SJ/T-11363-2006, EU Directive 2011/65/EU, and 2015/863/EU.

1. Chroma is not fully transitioned to lead-free solder assembly at this moment; however, most of the components used are RoHS compliant.
2. The environment-friendly usage period of the product is assumed under the operating environment specified in each product's specification.
3. This product complies with EU REACH regulations and no SVHC is in use.

Disposal

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being. When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliances for disposal at least free of charge.





Declaration of Conformity

For the following equipment :

AC/DC/IR Hipot Tester

(Product Name/ Trade Name)

19071, 19073

(Model Designation)

CHROMA ATE INC.

(Manufacturer Name)

88 Wenmao Rd., Guishan Dist., Taoyuan City 333001, Taiwan

(Manufacturer Address)

Is herewith confirmed to comply with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility (2014/30/EU) and Low Voltage Directive (2014/35/EU). For the evaluation regarding the Directives, the following standards were applied :

EN 61326-1:2013, Table 2, CISPR 11:2009+A1:2010, Group 1 Class A

EN 61000-3-2:2006+A1:2009+A2:2009, Class A, EN 61000-3-3:2013

IEC 61000-4-2:2008, IEC 61000-4-3:2006+A1:2007+A2:2010, IEC 61000-4-4:2012,

IEC 61000-4-5:2005, IEC 61000-4-6:2008, IEC 61000-4-8:2009, IEC 61000-4-11:2004

IEC 61010-1:2010, EN 61010-1:2010

IEC 61010-031:2002+A1, EN 61010-031:2002+A1

IEC 61010-2-030:2010, EN 61010-2-030:2010

The equipment describe above is in conformity with Directive 2011/65/EU and 2015/863/EU of the European Parliament and of the Council on the restriction of the use of certain hazardous substances in electrical and electronic equipment.

The following importer/manufacturer or authorized representative established within the EUT is responsible for this declaration :

CHROMA ATE INC.

(Company Name)

88 Wenmao Rd., Guishan Dist., Taoyuan City 333001, Taiwan

(Company Address)

Person responsible for this declaration:

Mr. Vincent Wu

(Name, Surname)

T&M BU Vice President

(Position/Title)

Taiwan

(Place)

2020.12.23

(Date)

Vincent Wu

(Legal Signature)

Safety Summary

The following general safety precautions must be observed during all phases of operation, service, and repair of this product. Failure to comply with these precautions or specific WARNINGS given elsewhere in this manual will violate the safety standards of design, manufacture, and intended use of the instrument. *Chroma* assumes no liability for the customer's failure to comply with these requirements.




BEFORE APPLYING POWER

Verify that the power is set to match the rated input of this device.



PROTECTIVE GROUNDING

Make sure to connect the protective grounding to prevent an electric shock before turning on the power.



NECESSITY OF PROTECTIVE GROUNDING

Never cut off the internal or external protective grounding wire, or disconnect the wiring of the protective grounding terminal. Doing so will cause a potential shock hazard that may bring injury to a person.



FUSES

Only fuses with the required rated current, voltage, and specified type (normal blow, time delay, etc.) should be used. Do not use repaired fuses or short-circuited fuse holders. To do so could cause a shock or fire hazard.



DO NOT OPERATE IN AN EXPLOSIVE ATMOSPHERE

Do not operate the instrument in the presence of flammable gases or fumes. The instrument should be used in an environment of good ventilation.



DO NOT REMOVE THE COVER OF THE INSTRUMENT

Operating personnel must not remove the cover of the instrument. Component replacement and internal adjustment can be done only by qualified service personnel.

Safety Symbols

	DANGER – High voltage.
	Explanation: To avoid injury, death of personnel, or damage to the instrument, the operator must refer to the explanation in the manual.
	High temperature: This symbol indicates the temperature is hazardous. Do not touch to avoid personal injury.
	Protective grounding terminal: This symbol indicates that the terminal must be connected to the ground before operating the equipment to protect against electrical shock in case of a fault.
	Functional grounding: To identify an earth (ground) terminal in cases where the protective ground is not explicitly stated. This symbol indicates the power connector does not provide grounding.
	Frame or chassis: To identify a frame or chassis terminal.
	Alternating Current (AC)
	Direct Current (DC) / Alternating Current (AC)
	Direct Current (DC)
	Push-on/Push-off power switch
	The WARNING sign highlights an essential operating or maintenance procedure, practice, condition, statement, etc., which if not strictly observed, could result in injury to, or death of, personnel or long-term health hazards.
	The CAUTION sign highlights an essential operating or maintenance procedure, practice, condition, statement, etc., which if not strictly observed, could result in damage to, or destruction of, equipment.
	The Notice sign highlights an essential operating or maintenance procedure, condition, or statement.

Danger of Operating

1. When the instrument is under output voltage, please do not touch test area or you may shock hazard and result in death.


Please obey the following items.

- Make sure the grounding cable is connected correctly and using the standard power cord.
 - Do not touch the output terminal.
 - Do not touch test cable of connecting test terminals.
 - Do not touch any unit under test.
 - Do not touch any component that is connected to the output terminal for charging.
 - Do not touch the test unit right after the test has ended or when the output has just been turned off. It can take several seconds for the high voltage to bleed off.
2. The shock accidents are usually occurred on the following conditions.
 - The grounding terminal of the instrument doesn't connect correctly.
 - No use insulation glove for testing.
 - After test is completed to touch test unit immediately.
 3. Remote control for the instrument: This instrument provided with remote control, normally using the external signal to control high voltage output. For safety reasons and prevent from hazards, please exactly follow instructions below while using remote control.
 - Unexpected high voltage output may exist. Make sure if this instrument is under testing/remote controlling before access to the probes.
 - When the instrument is under testing/operating, any access to DUT, test cable and probe output terminal are prohibited, both for the operator/service personnel.
 - Normally remote control of this instrument is controlled by the high voltage test bar. However, using of other control circuit is also possible. For safety reasons and prevent from hazards, please notice that unintentional access to the control test bar or bridging the control circuit to high voltage terminal and test cables may cause hazards. Please keep this terminal/control from unintentional bridging/access to avoid danger.

⚠ WARNING

1. Do not tie the HV cable, RS232, Handler, GPIB control cable and other low voltage cable together. It could damage the product or PC controller.
2. To avoid fire, heat and electrical related hazards, always check cable attachment of alligator clipper and connector for both COMMON (RTN/LOW) and OUTPUT (High voltage output) terminals before operating to make sure no conductor test cable is loosen or damaged.

DANGER



Storage, Freight, Maintenance, and Cleaning

Storage

When not in use, pack the device properly and store in a suitable environment.

Freight

Pack the device carefully before moving it. If any of the original packing material is missing, use suitable alternative material and mark it “fragile” and “keep away from water” to avoid damaging the product. This product is a piece of precision test equipment; do not drop or hit it.

Maintenance

In case of any malfunction or abnormality, refer to the manual, or contact your local distributor for prompt service. Do not touch any parts inside the instrument to avoid any danger to yourself or damage to the product.

Cleaning

Be sure to unplug the input power cord from the device and remove all other connected wires before cleaning. Use a brush to clean the dust off the machine surface and a low pressure air gun to clean the dust inside the device or send it to your local distributor for cleaning.

Revision History

The following lists the additions and modifications in this manual at each revision.

Date	Version	Revised Sections
Jan. 2003	1.0	Complete this manual.
April 2003	1.1	Modify "Specifications (18°C ~ 28°C RH ≤ 70%)" "Standard Accessory" "Rear Panel" "RS-485 Interface" "Solving Problems"
Dec. 2003	1.2	Modify "Introduction" "Rear Panel" "Operation" "Auto Range" "Calibration Procedure" "Command Description"
March 2004	1.3	Add "RS485 Interface (Optional)" Add "The Danger of Operating" "Storage. Freight. Maintenance. Disposal" Modify "Specifications (18°C ~ 28°C RH ≤ 70%)" "Rear Panel"
Sep. 2004	1.4	Modify "Product Features" "Optional Accessory" "Rear Panel" "PROGRAM Parameter Setting" "How to Perform Tests" "RS485 Interface (Option)"
March 2005	1.5	Modify "Introduction" "System Setup" "PROGRAM Parameter Setting" "How to Perform Tests" "KEY LOCK Function" "Command List" "Command Description"
Aug. 2006	1.6	- Add "CE Statement of Conformity" - Add the description of "Power Cord (W12 030080)" to the section of "Standard Accessory" - Add the section of "Initial Inspection"
Nov. 2006	1.7	- Modify the description of Disposal in "Storage, Freight, Maintenance & Disposal" - Modify the descriptions of RS-485 command in the section of "Command Description".
March 2007	1.8	Add "Material Contents Declaration"
Dec. 2007	1.9	Modify the following: - "I-RUS" in the section of "PROGRAM Parameter Setting". - "Inrush" in DC Mode table in the section of "Command Description".
Dec. 2008	2.0	Modify the following: - Description of "Hipot" item in the section of "Specifications". - Description of table in the section of "Standard Accessory". - "(3) System Parameter Setting Table" in the section of "System Setup".

		- <i>"PRESET parameter function table"</i> in the section of <i>"PRESET Parameter Setting"</i>. - Menu of <i>"Open/Short Detection Mode (OS)"</i> in the section of <i>"PROGRAM Parameter Setting"</i>. - <i>"Test Steps (OS) Standby Menu"</i> & <i>"Description Table for Test Result"</i> in the section of <i>"How to Perform Tests"</i>. - <i>"CONFIRM Window"</i> in the section of <i>"Change User Password"</i>. - Description in the section of <i>"Command Description"</i>.
Nov. 2009	2.1	Add <i>"RS-232 interface"</i> .
Jun. 2010	2.2	Add two new items in <i>"Solving Problems"</i> .
Dec. 2010	2.3	Modify <i>"Material Contents Declaration"</i> .
Mar. 2011	2.4	Add <i>"Timing Diagram"</i> .
Sep. 2011	2.5	Add <i>"IR Range Selection"</i> .
Mar. 2012	2.6	Modify the following: - <i>"CE Declaration"</i>. - Figure 2-4 in the section of <i>"Remote Control"</i>. - Description of <i>"Time T2"</i> in the section of <i>"Timing Diagram"</i>.
Dec. 2012	2.7	Modify the figure of item (2) in the section of <i>"DCA Calibration (DC/IR MODE)"</i> .
Dec. 2013	2.8	Add Standard warnings to the section of <i>"Solving Problems"</i> .
Jan. 2015	2.9	Add the warning to <i>"The Danger of Operating"</i> section.
Sep. 2016	3.0	Modify <i>"CE Declaration of Conformity"</i> .
Dec. 2016	3.1	Modify the following: - Rear panel figure. - Figure 2-1, figure 2-2, figure 2-3 and figure 2-4 in <i>"Remote Control"</i>. - Table and timing diagrams in <i>"Timing Diagram"</i>.
Apr. 2017	3.2	Modify the following: - <i>"Material Contents Declaration"</i>. - <i>"CE Declaration of Conformity"</i>.
Nov. 2021	3.3	Update address and <i>"PROGRAM Parameter Setting"</i> section in <i>"Operation and Setting"</i> chapter.
Nov. 2022	3.4	Update <i>"Standard Accessory"</i> .
Jun. 2024	3.5	Modify <i>"Command Description"</i> in <i>"RS485 Interface"</i> chapter

Table of Contents

1.	Introduction.....	1-1
1.1	Functions Overview	1-1
1.2	Product Features	1-1
1.3	Specifications (18°C ~ 28°C RH ≤ 70%)	1-3
1.4	Standard Accessory	1-5
1.5	Optional Accessory	1-5
1.6	Initial Inspection	1-5
2.	Operation and Setting	2-1
2.1	Front Panel	2-1
2.1.1	Display Area	2-1
2.1.2	Button Area	2-2
2.1.3	Terminal Area	2-2
2.2	Rear Panel.....	2-3
2.3	Operation	2-6
2.3.1	Memory Process	2-6
2.3.2	System Setup.....	2-7
2.3.3	PRESET Parameter Setting	2-9
2.3.4	PROGRAM Parameter Setting	2-9
2.4	How to Perform Tests.....	2-13
2.5	Other User Setting Function.....	2-17
2.5.1	KEY LOCK Function.....	2-17
2.5.2	Auto Range	2-17
2.5.3	Change User Password.....	2-18
2.5.4	Remote Control	2-19
2.5.5	Output Signal	2-21
2.5.6	Timing Diagram	2-21
3.	Installation and Maintenance	3-1
3.1	Notices for Installation.....	3-1
3.1.1	Charging During DC HiPot/Insulation Resistance Test.....	3-2
3.1.2	Emergency Events	3-3
3.1.3	Solving Problems	3-3
3.2	Notices for Maintenance	3-5
3.3	Troubleshooting	3-5
3.4	Input/Output Pin Assignment.....	3-6
4.	Calibration Procedure	4-1
4.1	Calibration.....	4-2
4.2	Voltage Calibration.....	4-2
4.2.1	Connection Diagram.....	4-2
4.2.2	ACV Calibration (AC Mode).....	4-2
4.2.3	DCV Calibration (DC/IR MODE)	4-3
4.2.4	IRV Calibration (DC/IR Mode).....	4-4
4.3	Current Calibration.....	4-5
4.3.1	Connection Diagram.....	4-5
4.3.2	ACA Calibration (AC MODE)	4-5
4.3.3	DCA Calibration (DC/IR MODE)	4-6
4.4	ARC Calibration	4-8
4.4.1	Connection Diagram.....	4-8
4.4.2	AC ARC Calibration (AC MODE)	4-8
4.4.3	DC ARC Calibration (DC MODE).....	4-9

4.5	IRR Calibration (IR Mode).....	4-10
4.5.1	Connection Diagram.....	4-10
4.5.2	Insulation Resistance Calibration.....	4-10
4.6	Ground Continuity Calibration	4-12
4.6.1	Connection Diagram.....	4-12
4.6.2	Description of Ground Continue Calibration.....	4-12
4.7	LCD Contrast Calibration	4-13
4.8	Complete Calibration	4-13
5.	RS485 Interface (for Model 19073 + RS485)	5-1
5.1	Description of Function	5-1
5.2	Parameter Setting	5-1
5.3	Terminal and Pin Signal Connection.....	5-2
5.4	Communication Protocol	5-3
5.5	Commands List.....	5-4
5.6	Command Description.....	5-4
5.7	Flow Diagram.....	5-25
6.	RS232 Interface	6-1
6.1	Guide	6-1
6.2	Interface Specification.....	6-1
6.3	RS-232 Single Unit Connection for Parameter Setting	6-1
6.4	Connector	6-1
6.5	Method of Connecting	6-2
6.6	Communication Protocol	6-2
7.	Maintenance	7-1
7.1	General.....	7-1
7.2	Instrument Return	7-1

1. Introduction

1.1 Functions Overview

- This high quality automatic HiPot test instrument is designed to test the withstanding leakage current and insulation resistance for electric machinery and electronic devices.
- For the withstanding test, its output power is AC: 100VA (5kV, 20mA), DC: 30VA (6KV, 5mA), which applies to electronic, electric machinery and components for withstanding and insulation tests.
- For insulation resistance, its test range is from 0.1M Ω ~50G Ω and the test voltage is 0.050kV ~1kV definable.
- For ground continue, its test range is from 0 Ω ~5 Ω .
- For short/open detection, before testing high voltage test if the capacitance is short or open circuit in advance. To ensure the DUT is in good contact then to perform a high voltage test.
- All settings for state, time, current, voltage, and resistance can be seen clearly on the display. There is no need to memorize the parameter state of any items.
- It is equipped with devices for Pass/Fail judgment, test results, and remote control.
- It can perform high efficiency and accurate tests for electric machinery, electronic devices, and components.

1.2 Product Features

- **Multiple Test States**
This instrument can select a single item for the test, such as the AC withstanding test, DC withstanding test, insulation resistance test, ground continue test, and short/open detection test.
- **Clear Display**
This instrument has the clearest design for setting the parameters of test voltage, current states, readings, procedures, and states. All of them can be read from the display directly.
- **High/Low Limit Comparator for Pass/Fail Judgment**
The function of high/low limit comparator for Pass/Fail judgment is designed for both withstanding and insulation resistance tests. The HiPot low limit comparator and insulation high limit comparator are generally designed to prevent misjudgment due to bad connection or test cable tripped. This function can detect if there is any bad connection or broken line.

- **Remote Control**

This instrument can extend [START] and [RESET] signals to control externally. Usually, they are connected to a high voltage test gun or control case.

- **Changing the Time for Voltage Rising**

This instrument contains [RAMP] function. This function is to change the time required for the outputted test voltage from zero rising to the specified value.

- **Changing the Time for Voltage Falling**

This instrument contains the [FALL] function. This function is to change the time required for the outputted test voltage from the specified value falling to zero.

- **Current Range Auto Switch**

There are two HiPot test AC ranges, one is low AC range 0 ~ 3.000mA, and the other is AC 3.01~20mA. There are three DC ranges, low current range 0 ~ 300uA, current range 0.301mA ~ 3mA and current range 3.01mA ~ 5.00mA. When the testing current is small, you can set it to switch the current range to the low one automatically for higher resolution via software as needed.

- **RS-232 Connection (for the model with RS-232 only)**

The tester that can use an RS-232 interface card and PC mainframe performs a connection test.

- **RS-232 and RS-485 Interface Multi-connection Test (For the model with RS-485 only)**

The tester that can use the RS-232 interface card or install the RS-485 interface card and PC mainframe performs a connection test. The maximum is 31 sets of instruments to process connection tests with the PC mainframe using an RS-485 interface card simultaneously. Also, the PC mainframe can control the setting and read the test data. When there is no PC mainframe, multi-connection tests can be performed individually but the test data cannot be read.

1.3 Specifications (18°C ~ 28°C RH ≤ 70%)

Withstanding Voltage Test	
Test Voltage	AC: 0.05~5kV / DC: 0.05~6kV Constant Voltage (19072, 19073 only)
Voltage Regulation	≤ 1%+5V, Rated Load
V-display Accuracy	± (1% of reading + 5 counts), 2V resolution
Cutoff Current (Note1)	AC: 0.1mA ~ 20mA, DC: 0.01mA ~ 5mA (Note1), 0.1uAdc resolution
I-display Accuracy 0.1uA-299.9uA 0.3mA-2.999mA 3mA-20mA(5mAdc)	± (1.5% of reading + 5 counts) (Note2) WDC only ± (1.5% of reading + 5 counts) (Note2)
Output Frequency	50Hz, 60Hz
Test Time	0.1 ~ 999 Sec, continue (Note3)
Dwell Time	0.1 ~ 999 Sec, off
Ramp Time	0.1 ~ 999 Sec, off (0.1sec approx.)
Fall Time	0.1 ~ 999 Sec, off
Arc Detection	
Setting Mode	Programmable Setting
Detection Current	AC: 1mA ~ 20mA, DC: 1mA ~ 5mA
Min. pulse width	10us approx.
GOOD/NO-GO Judgment Function	
Judgment System	- Window comparator - A NO-GO judgment is made when a current greater than the high limit value or smaller than the low limit value is detected. - When a NO-GO judgment is made, the output voltage is cut out and a NO-GO alarm signal is delivered. - If no abnormal state is detected during the test time a GOOD Judgment is made and a GOOD signal is delivered.
Insulation Resistance Test (19073 only)	
Test Voltage	DC: 0.05kV ~ 1kV, Constant Voltage
V-display Accuracy	± (5% of reading + 5 counts) (open voltage), 2V resolution
Resistance Range	0.1 MΩ ~ 50 GΩ (Note 4)
Measuring Accuracy	≥ 500V: 1MΩ ~ 1000MΩ: ± 4% + 5 counts 1GΩ ~ 10GΩ: ± 7% + 5 counts 10GΩ ~ 50GΩ: ± 12% + 5 counts < 500V: 0.1 MΩ ~ 1000MΩ: ± 7% + 5 counts < 100V: 0.1 MΩ ~ 1000MΩ: ± 10% + 5 counts
Secure Protection Function	
Fast Output Cut-off	Approx. 0.4mS, after NG happens
Fast Discharge	Approx. 0.2S, Typical
Ground Fault Interrupt	0.5mA ± 0.25mAac (ON), OFF
Continuity Check	0.1Ω ~ 5.0Ω ± 0.2Ω, GC MODE
Panel Operation Lock	YES
Memory Storage	
Memories, Steps	10 steps or 60 groups for total 60 memory location
GO/NG Judgment Window	

□ Indication, Alarm	GO: (Short Sound) NG: W-Arc, W-Hi, W-Lo, IR-Lo, IR-Hi, GFI (Long Sound)
□ Remote Connector	
□ Rear Panel 9 Pin D-type Connector	Input: Start, Stop, Interrupt Output: Under test, Pass, Fail
□ TEST/RESET Control	Low - active control (24V open voltage typical). Input requirements:
	Input time duration: 20 msec. approx The above input circuits are not isolated from other internal circuits.
□ Options	
□ RS-232 Interface	Baud rate: 4800 ~ 19200, data bits: 8, stop bit: 1
□ RS-485 Interface	A maximum of 32 devices connected to each bus
□ Ambient Temperature and Relative Humidity	
□ Specifications range	18 to 28°C (64 to 82°F), ≤ 70% RH.
□ Operable range	Maximum relative humidity is 80% for temperatures up to 31°C (88°F). Decreasing linearly to 50% relative humidity at 40°C (104°F) Altitude up to 2000m Indoor use only Pollution degree 2
□ Storage range	-10 to 60°C (-14 to 140°F), ≤ 80% RH.
□ Installation Category	CAT II
□ Power Requirement	
□ Line Voltage	AC 100V, 120V, 220V ± 10%, 240V +5 -10%
□ Frequency	50 or 60 Hz
□ Power	No load: < 60W
□ Consumption	With rated load: 300W max.
□ General	
□ Dimension	270(W) x 105(H) x 350(D) mm
□ Weight	Approx. 12kg
□ Safety	
□ Ground Bond	Less than 100mΩ at 25Amp, 3sec
□ Hipot	Less than 10mA at 1.5kVac, 3sec
□ Insulation Resistance	Over 100MΩ at 500V 3sec
□ Line leakage current	Less than 3.5mA at 127V, 3sec, normal, reverse

- Note**
1. AC set over 75VA, DC set over 22.5VA the maximum operating time is 60 seconds, and the same as rest time.
The period of rest time is 1/2 duty of operating time. For full rating output, the line input range is +10% ~ -0%.
 2. Only refer to the 1.2kV resistance load.
 3. IR test time is 0.3 sec ~ 999 sec.
 4. The display resistance range is up to 60GΩ.

1.4 Standard Accessory

Item	Qty	Description
USA-type power cord	1	90° elbow USA-type power cord, length 1.8m
Power adapter	1	USA-type power cord 3P – 2P adapter
Test cable for HV terminal	1	Alligator clip – cross HV head, red HV test cable, wire length 1m
Test cable for LOW terminal	1	Alligator clip – banana plug, black HV test cable, wire length 1.2m
Test cable of grounding continuity	1	Cable for GC test, length 1.2m
3.15A fuse	2	For 3.15A SLOW 110VAC used
1.6A fuse	2	For 1.6A SLOW 240VAC used
Quick Start Guide	2	One English and one Traditional Chinese version

1.5 Optional Accessory

Item	Qty	Description
RJ-45 twin head connection cable	1	L: 450mm
RJ-45 twin head connection cable	1	L: 1000mm
RJ-45 twin head connection cable	1	L: 2000mm
RJ-45 twin head connection cable	1	L: 4000mm
DB-9F single-head connection cable	1	L: 7000mm
Across HV head + HV cable	1	L: 2000mm
Black banana head + HV cable	1	L: 2000mm

Remark: The optional accessory is for Model 19073 + RS485 only.


1.6 Initial Inspection

Before shipment, this instrument was inspected and found to be free of mechanical and electrical defects. As soon as the instrument is unpacked, inspect for any damage that may have occurred in transit. Save all packing materials in case the instrument has to be returned. If damage is found, please file a claim with the carrier immediately. Do not return the instrument to Chroma without prior approval.

2. Operation and Setting

2.1 Front Panel

The front panel is divided into several function areas. This section explains each control and the information displays on the LCD.



2.1.1 Display Area

- **Function Key Display Area:** Different function text appears in different menus. The mapping function keys (F1-F4) are located on the right. The function key is invalid if the text is blank.
- **Status Line:** This line shows the setting mode, value range, and test results.
- **RMT:** When the text is highlighted, it means the system is under on-line status.
- **LOCK:** When the text is highlighted, it means the system is under protection via parameter.
- **OFST:** When the text is highlighted, it means the leakage current has been offset by the system.

- **ERR**: When the text is highlighted, it means the system transmission is an error.
- **Test State Indicator**: The DANGER indicator indicates the instrument is under test condition and there is high voltage or mass current output on the test terminal when lights up. Do not touch the test terminal at this time.
- **Pass Indicator**: When it lights up it indicates the DUT passes the test. This indicator remains lit up until [STOP] is pressed.
- **Fail Indicator**: When it lights up it indicates the DUT fails the test. This indicator remains lit up until [STOP] is pressed.

2.1.2 Button Area

- **Power Switch**: The switch to supply the AC power source for this instrument.
- **Stop Button [STOP]**: Press this button the instrument will return to the ready state for testing and cut out output as well as clear all judgments.
- **Start Button [START]**: Press this button the instrument will be in the test state, which means there are outputs at the test terminal and all judgment functions are activated.
- **Calibration Switch**: It is used by Chroma for calibration before shipping the product. Nonprofessional is prohibited from using this function to avoid causing any damage.
- **Function Keys**: There are different functions in different display menus. The mapping function description text is at the right of the menu. The function key is invalid if the description text is blank.


2.1.3 Terminal Area

- **High Voltage Output Terminal**: The terminal of high voltage with high potential is located at the high potential terminal for high voltage output. This test terminal is very dangerous especially when the DANGER indicator is lit up. Do not touch it when there is high voltage output.
- **Common Test Terminal (RET/LOW)**: It is the reference terminal at high voltage test, i.e. the low potential terminal almost equals the chassis grounding.


2.2 Rear Panel

The rear panel is divided into several areas. This section describes the function of each area.


The standard rear panel of 19071/19072/19073:



The rear panel for the connection test model of 19073 + RS232 is shown below:



The rear panel for the connection test model of 19073 + RS485 is shown below:



(1) REMOTE CONTROL

- The connection diagram of remote control signals is as follows.



- START: The input terminal for the start test signal.
- RESET: The input terminal for stop test signal.
- COM: The common input terminal for START and RESET signals.
- UNDER TEST: This terminal will short-circuit when in test mode, thus it can be used to control the external signal. The connecting point specification is 115V AC with a current of less than 0.3A. The action time is from when the instrument enters the test mode until it is reset or completes the test.
- PASS: This terminal will short-circuit when the DUT passes the tests, thus it can be used to control the external signal. The connecting point specification is 115V AC with a current of less than 0.3A. The action time from the DUT is passed until it is reset.

(2) VOLTAGE SELECTOR: Input Power Range Switch

- To change the input AC power source for the following 4 types:
 - Voltage range 90V ~ 110V AC (3.15AT, 250V)
 - Voltage range 108V ~ 132V AC (3.15AT, 250V)
 - Voltage range 198V ~ 242V AC (1.6AT, 250V)
 - Voltage range 216V ~ 250V AC (1.6AT, 250V)
- Be sure to use the correct fuse when switching the power source.

(3) AC LINE: AC Power Socket and Fuse Holder

It is a three-pin power socket and a fuse holder. AC power is inputted from this socket to supply the AC source needed by this instrument. For detailed usage and specification of fuse, see *Chapter 3 Installation and Maintenance*.

(4) EARTH GROUND TERMINAL: Terminal Grounding for Safety

Use appropriate tools to ground this terminal surely. If it is not grounded surely, when the power circuit or any other device's connection is short-circuited with the ground terminal, the instrument chassis may contain high voltage. This is very dangerous as it may cause electric shock if anyone touches it under the situation; therefore, it is necessary to connect the ground terminal to the earth assuredly.

(5) CONTINUITY CHECK: Grounding continuity measurement and current output terminal

This function is for detecting ground continues of the DUT grounding terminal.


(6) FAN

The fan is activated simultaneously when the tester is powered on.

(7) Expanded Slot

The standard is a 5-pin terminal slot, this slot provides the following functions:

- The connection diagram of expanded slot signals is as follows.



- START: Input terminal of starting test signal.
- RESET: Input terminal of stopping test signal.
- COM: Input common terminal of START and RESET signals.
- INTERLOCK: It can output high voltage only when these two terminals are short-circuited.

(This function is only for installing a 5-pin terminal block on the expanded slot. If this unit is a 19073 + RS485 model, these two terminals are short-circuited fixedly.)

(8) HV OUTPUT Terminal

This terminal is the same as the HV output terminal of the front panel.

(9) Common Test Terminal: RET/LOW

This terminal is the same as the common test terminal of the front panel.

(10) RS-232 Interface Card:

This socket is for the RS-232 interface which is provided by the tester, it uses binary code transmission mode. Its command format is the same as the RS-485 interface.

(11) RS-485 Slot

This slot supports two sockets of RJ-45, which provides a multi-connection function for model 19073 + RS485.

2.3 Operation

[Standby Menu]: The screen appears as below after powered on.

STEP 1/ 1 AC	LOW :OFF	PROGRAM
0.000KV	ARC :OFF	
0.500mA	RAMP:OFF	PRESET
3.0s	FALL:OFF	
		MENU
		MORE..
STANDBY	RMT	LOCK OFST ERR

2.3.1 Memory Process

■ How to enter the Memory Process menu

(1) In **[Standby Menu]**, press the Function Key [MENU], it appears:

1. MEMORY	LAST
2. SYSTEM	
3. OPTION	DOWN
4. CALIBRATION	
5. KEY LOCK	SELECT
SELECT FUNC.	EXIT
RMT	LOCK OFST ERR

(2) Use Function Key [F1] and [F2] to move the highlight to "MEMORY", and press Function Key [F3] to enter the memory process menu as below:

1. (0 STEPS)	STORE
2. (0 STEPS)	
3. (0 STEPS)	RECALL
4. (0 STEPS)	
5. (0 STEPS)	DELETE
SELECT FUNC.	RETURN
RMT	LOCK OFST ERR

(3) At this time select execution action by pressing Function Key [F1], [F2] or [F3], it appears:

1. (0 STEPS)	LAST
2. (0 STEPS)	
3. (0 STEPS)	DOWN

4. (0 STEPS)	SELECT				
5. (0 STEPS)					
SEL. MEMORY	RMT	LOCK	OFST	ERR	RETURN

- (4) At this time use Function Key [F1] and [F2] to move the highlight to the memory for processing, then press Function Key [F3] will prompt a confirmation window. Press Function Key [ENTER] to confirm and Function Key [UP] or [DOWN] to select the stored character of the file name. Press [NEXT.C] to select the next character and [ENTER] to confirm the file name, the maximum file name is 10 characters.

1. (2 STEPS)HIPOT	UP				
2. (0 STEPS)	DOWN				
3. (0 STEPS)	ENTER				
4. (0 STEPS)	CANCEL				
5. (0 STEPS)					
SEL. MEMORY	RMT	LOCK	OFST	ERR	

- (5) When executing the [RECALL] or [DELETE] function, use Function Key [F1] and [F2] to move the highlight to the memory for processing, then press Function Key [F3] will prompt a confirmation window. Press Function Key [YES] to confirm or Function Key [NO] to cancel, then can recall or delete the memory set. Each memory contains test parameters, preset parameters, and the number of the test step.

1. (2 STEPS)HIPOT	LAST				
2. (0 STEPS)	DOWN				
3. (0 STEPS)	SELECT				
4. (0 STEPS)	RETURN				
5. (0 STEPS)					
SEL. MEMORY	RMT	LOCK	OFST	ERR	

2.3.2 System Setup

■ How to enter the SYSTEM SETUP menu

- (1) In [Standby Menu], press the Function Key [MENU] and by using Function Key [F1], [F2] to move the highlight to "SYSTEM" and then press Function Key [F3] to enter into the parameter setting menu as below:

1.CONTRAST	:	7	INC.
2.BUZZER VOLUME:		HIGH	DEC.
3.EN50191	:	OFF	NEXT
4.DC 50V AGC	:	ON	
5.PASS ON	:	OFF	
1-15		RMT	LOCK
		OFST	ERR
			RETURN

- (2) Use Function Key [F3] to move the highlight to the parameter item you want to set, then use Function Key [F1] and [F2] to set the parameter data.

(3) System Parameter Setting Table

Item	Range	Default	Description
CONTRAST	1~15	7	Adjust the LCD brightness
BUZZER VOLUME	HIGH/MEDIUM/LOW/OFF	HIGH	Adjust the buzzer volume
EN50191	ON/OFF	OFF	The output meets to EN50191 requirement (AC Max 3mA, DC Max 5mA). The set and stored measurement parameters won't be affected by changing this setting.
DC 50V AGC	ON/OFF	ON	Select if open hardware AGC as DC / IR voltage setting is 50V~1000V. (When this item is OFF, hardware AGC is opened only with DC voltage set to above 1001V automatically.)
PASS ON	OFF, 0.1sec-10sec	OFF	When setting the time to PASS ON, after the setting time for PASS ON is ended the PASS signal will be deleted automatically. When set time to OFF, the PASS signal continues until press any keys to delete.
END OF STEP	ON/OFF	OFF	When the setting is ON, as all STEPs are end the signal for Under Test will auto exit from 10mS. When the setting is OFF, only all STEPs are end the signal for Under Test will exit from 10mS.
EOT	END OF TEST / END OF TIMER	END OF TEST	1. END OF TEST (Pass & Fail & Under Test signals are activated after discharging.) 2. END OF TIMER (Pass & Fail & Under Test signals are activated before discharging.)

2.3.3 PRESET Parameter Setting

■ How to enter the PRESET menu

In **[Standby Menu]**, press Function Key [PRESET] to enter the PRESET menu as shown below:

1.AC.V FREQUENCY:	60Hz	UP
2.SOFTWARE AGC :	ON	DOWN
3.WV AUTO-RANGE:	OFF	NEXT
4.IR AUTO-RANGE:	ON	EXIT
5.GFI :	ON	
50Hz/60Hz	RMT	LOCK
	OFST	ERR

- (1) After entering the PRESET parameter setting menu, press Function Key [F3] to move the highlight to the parameter item you desire to set.
- (2) Press Function Key [F1] and [F2] to set the parameter data.
- (3) PRESET parameter function table as shown below:

Item	Range	Default	Description
ACV FREQUENCY	50 / 60 Hz	60Hz	It sets the output voltage frequency at the AC HiPot test.
SOFTWARE AGC	OFF / ON	ON	It sets if opening the software AGC function.
WV AUTO-RANGE	OFF / ON	OFF	It sets if opening the HiPot auto range function.
IR AUTO-RANGE	OFF / ON	ON	It sets if opening the insulation auto range function.
GFI	OFF / ON	ON	It sets if opening the GFI function.
FAIL RESTART	OFF / ON	OFF	It sets if restarting directly when fails the test.
SCREEN	OFF/ON	ON	It sets if displaying the test screen.

2.3.4 PROGRAM Parameter Setting

■ Test parameter setting

- (1) In **[Standby Menu]**, press Function Key [PROGRAM] to enter the PROGRAM setting menu as follows:

STEP 1/1 AC	LOW : OFF	NEW
VOLT :0.050kV	ARC : OFF	MORE..
HIGH :0.500mA	RAMP : OFF	NEXT
TIME : 3.0s	FALL : OFF	EXIT
1-10	RMT	LOCK
	OFST	ERR

■ Test steps setting

- (1) Press [F3] to move the highlight and stay in the test item. When Function Key [F1] shows "UP", it means pressing this key can switch to the next test step. When

Function Key [F1] shows "NEW", it means pressing this key can add a test step. When Function Key [F1] shows "FIRST", it means pressing this key can switch the first test step.

(2) Use Function Key [F2] can switch the functions as shown below:

STEP 2/2 AC	LOW : OFF	DELETE
VOLT :0.500kV	ARC : OFF	INSERT
HIGH :0.500mA	RAMP : OFF	DOWN
TIME : 3.0s	FALL : OFF	RETURN
VOLTAGE IS 0	RMT LOCK OFST ERROR	

(3) Function Key [DELETE] to delete a selected test step.

(4) Function Key [INSERT] to insert a new test step set.

(5) Function Key [DOWN] to select to previous test step set.

■ Selecting Test Mode

Press Function Key [F3] to move the highlight and stay in the test item. Use Function Key [F1] and [F2] to select the test mode. There are AC/GC/PA/OS, AC/DC/GC/PA/OS, and AC/DC/IR/GC/PA/OS test modes for selection by different models. Different test mode has different test parameters for setting.

- **Description of each test parameter setting:** The following explains the parameter setting of each test mode.

(1) AC HiPot Test Mode

STEP 1/1 AC	LOW : OFF	UP
VOLT:0.000kV	ARC : OFF	DOWN
HIGH:0.500mA	RAMP: OFF	NEXT
TIME: 3.0s	FALL: OFF	EXIT
SELECT MODE	RMT LOCK OFST ERR	

VOLT : Set the required voltage for the HiPot test.

HIGH : Set the upper limit for leakage current.

TIME : Set the required time for testing, 0 means continuous test. (Judge the high and low limit for leakage current during the time.) The voltage value is shown which within specification, the minimum test time should be ≥ 0.3 second. When the displayed voltage is not reached to 9/10(Software AGC ON) or 2/3(Software AGC OFF) of setting voltage value, the judgment function will show FAIL.

LOW : Set the low limit for leakage current, 0 means OFF.

ARC : Set the high limit for ARC, 0 means OFF.

RAMP : Set the required time for rising to the selected voltage, 0 means OFF.

FALL : Set the required time for falling from the selected voltage to zero, 0 means OFF.

(2) DC HiPot Test Mode

STEP 1/1	DC	LOW : OFF	UP
		ARC : OFF	
VOLT : 0.000kV		RAMP : OFF	DOWN
HIGH : 0.500mA		DWELL : OFF	
TIME : 3.0s		FALL : OFF	NEXT
		I-RUS : OFF	
SELECT MODE	RMT	LOCK	OFST
		ERR	EXIT

- VOLT : Set the required voltage for the HiPot test.
HIGH : Set the high limit for leakage current.
TIME : Set the required time for testing, 0 means continuous test. (Judge the high and low limit for leakage current during the time.) The voltage value is shown which within specification, the minimum test time should be ≥ 0.2 second. When the displayed voltage is not reached to 9/10 (Software AGC ON) or 2/3 (Software AGC OFF) of setting voltage value, the judgment function will show FAIL.
LOW : Set the low limit for leakage current with a value less than the high limit for leakage current or OFF.
ARC : Set the high limit for ARC, 0 means OFF.
RAMP : Set the required time for rising to the selected voltage, 0 means OFF.
DWELL : Set DWELL time, 0 means OFF. (Do not judge the high and low limit for leakage current during DWELL TIME operation, but do not over the high limit of setting range.)
FALL : Set the required time for falling from the selected voltage to zero, 0 means OFF.
I-RUS : Select if the detection charge current over low function is activated.

(3) Insulation Resistance Test Mode

STEP 1/1	IR	HIGH : OFF	UP
		RANGE: AUTO	
VOLT : 0.000kV		RAMP : OFF	DOWN
LOW : 1.0M Ω		DWELL : OFF	
TIME : 3.0s		FALL : OFF	NEXT
SELECT MODE	RMT	LOCK	OFST
		ERR	EXIT

- VOLT : Set the required voltage for the insulation resistance test.
LOW : Set the low limit for insulation resistance.
TIME : Set the time required for the test, 0 means continuous test. (Judge the high and low limit for insulation resistance during the time.)
HIGH : Set the high limit for insulation resistance with a value larger than the low limit of insulation resistance or OFF.
RANGE : Set the current test range of insulation resistance, AUTO indicates auto switch range. The relation between the current range and resistance measurement range is shown below.

Range	IR Display Value	
	Setting Voltage 50V ~ 250V	Setting Voltage 250V ~ 1000V
5mA(3~5mA)	0.1MΩ~0.1MΩ	0.1MΩ~1.0MΩ
3mA(0.3~3mA)	0.1MΩ~0.9MΩ	0.1MΩ~3.5MΩ
300uA(30~300uA)	0.1MΩ~9.0MΩ	0.1MΩ~25.0MΩ 22.0MΩ~35.0MΩ
30uA(3~30uA)	0.10MΩ ~ 25.00MΩ 22.0MΩ ~ 90.0MΩ	0.10MΩ ~ 25.00MΩ 22.0MΩ ~ 250.0MΩ 0.220GΩ ~ 0.350GΩ
3uA(0.3~3uA)	22.0MΩ ~ 250.0MΩ 0.220GΩ ~ 0.900GΩ	25.0MΩ ~ 250.0MΩ 0.220GΩ ~ 2.500GΩ 2.20GΩ ~ 3.33GΩ
300nA(20~300nA)	0.200GΩ ~ 2.000GΩ	0.200GΩ ~ 2.500GΩ 2.20GΩ ~ 50.00GΩ

Note : Select IR suitable current range please follow the test voltage and DUT insulation resistance for counting the quantity of current then follow it to select a suitable current range.

RAMP: Step-up setting voltage needed time, 0 means OFF.

DWELL: Set the required time for the test, 0 means OFF. (Do not judge the high and low limit for insulation resistance during this period.)

FALL : Set the required time for falling from the selected voltage to zero, 0 means OFF.

(4) Ground Continue Mode

STEP 1/1	GC	LOW : OFF	UP
CURR :	0.0A		DOWN
HIGH :	1.0Ω		NEXT
DWELL:	0.3s		EXIT
SELECT MODE	RMT	LOCK	OFST
ERR			

CURR : Set the output current (0.1A maximum).

HIGH : Set the high limit of ground continue (0.1Ω ~ 5Ω).

DWELL : Set the time required for the test (0.1 sec ~ 1 sec). (Do not judge the high and low limit for ground continue during the time.)

LOW : Set the low limit for ground and continue with the value lower than the high limit of ground continue or OFF.

(5) Pause Mode

STEP 1/1	PA	UP
PAUSE:PAUSE-MODE		DOWN
UNDER TEST SIGNAL:OFF		NEXT
SELECT MODE	RMT	LOCK
OFST	ERR	EXIT

PAUSE : Set the signal shown on the menu when pausing, the maximum length is 15 characters.

UNDER TEST SIGNAL: Set UNDER TEST signal on the rear panel and DANGER indicator on the front panel when pausing.

(6) Open/Short Detection Mode (OS)

STEP 1/1	OS	OPEN : 50%	UP
		SHORT: OFF	DOWN
			NEXT
SELECT MODE	RMT	LOCK	ERR
			EXIT

OPEN : Set the judgment test result as the condition for open (compare the test reading with the standard capacitance value[Cs] be read).

SHORT : Set the judgment test result as the condition for short (compare the test reading with the standard capacitance value[Cs] be read).

2.4 How to Perform Tests

■ Test Cable Offset Calibration


- (1) In **[Standby Menu]**, press Function Key [MORE..] to enter the test menu of multiple STEPS.
- (2) Press Function Key [OFFSET], and the monitor will show a menu to indicate you to open the output terminal.
- (3) Press [START], the DANGER indicator on the front panel will light up. The test time is 5 seconds. The system starts to measure the test cable offset and shows the reading on the monitor, then saves it to memory.

■ Connection the DUT

First, ensure there is no voltage output and the DANGER indicator is off. Then connect the low potential test cable (black) to the common test terminal on the system, and secure it with the fixed plate. Short-circuit the test cable and high voltage output terminal. After confirming no high voltage is output, connect the DUT with the low potential test cable first and high potential test cable later, and then plug in the high voltage test cable (red or white) to the "High Voltage Output Terminal".

■ Test Steps(AC/DC/IR/GC)

- (1) Connection the DUT with correct procedures.
- (2) In **[Standby Menu]** (as shown below):



1. STEP 1/2 in "Line 1" indicates there are 2 test steps, and it is executing step 1 at present. M02 1/2 in "Line 1" indicates this test parameter set has been saved into the index 2 memory. There are 2 test steps in the memory, and it is executing step 1 at present.
2. AC in "Line 1" indicates this step is AC HiPot test mode.
3. "Line 2" indicates the output voltage set for the test.
4. "Line 3" indicates the high limit for leakage current under STANDBY state in AC or DC HiPot test mode; or the low limit for insulation resistance under STANDBY state in IR test mode. When in TEST mode, it is the value of real leakage current or insulation resistance.
5. "Line 4" indicates the testing time set under the STANDBY state; or the remaining testing time under the TEST state.
6. "Line 5" is the "Status Line" that shows the current state or test results.

(3) Press [STOP] to enable it to standby for test and the "Status Line" shows "STANDBY".

(4) Press [START] to begin the test. It will begin to output the test voltage. The DANGER indicator lights up and the "Status Line" shows "UNDER TEST" to warn you that it is in a test state and there is mass voltage output. "Line 2" will show the output voltage reading, "Line 3" will show the reading of leakage current or insulation resistance, and "Line 4" performs timing and countdown work.

(5) PASS Judgment

When all test steps are done and the "Status Line" shows PASS, it indicates the DUT is a quality product. Then the output is cut out, rear panel outputs the PASS signal and buzzer (short beep) in the meantime.

(6) FAIL Judgment

If the measurement is abnormal, the system will judge the DUT as a failed product and cut out the output. The rear panel outputs a FAIL signal and buzzer (long beep) in the meantime. The action continues until the [STOP] key is pressed. "Status Line" will show the fail state as below. Please see "Description Table for Test Result".


(7) If any errors happen and cause the [START] key to be locked, you can press [STOP] to release it.

(8) You can press the [STOP] key anytime to stop the test output in any case.

■ Test Steps (OS)

(1) Connection the DUT with correct procedures.

(2) In **[Standby Menu]** (as shown below):



1. OS in “Line 1” indicates this step is **open/short detection mode**.
2. “Line 2” indicates the output voltage set for the test.
3. “Line 3” indicates the capacitance value for reading.
4. “Line 4” indicates the test time.

(3) Press [STOP] to enable it to standby for test and the “Status Line” shows “STANDBY”.

(4) Please press [MORE..] to enter the test menu of multiple STEPS, the menu as shown below:

		OUTPUT	MEASURE	RESULT	OFFSET
1	OS	0.100kV	0.0nF	-----	
					GET Cs
					MORE..
		STANDBY	RMT	LOCK	OFST
			ERR		

1. Please press [OFFSET] to perform OFFSET elimination at first. It needs to perform OFFSET elimination again when changing the wire or fixture every time. This is to ensure the accuracy of the test.
2. It needs to treat the capacitance standard sample as the DUT when testing or changing a new capacitance DUT. Press [GET Cs] to read the standard capacitance value for the value when tested.
3. Please press [MORE..] again to back to the standby menu.
4. Press [START] to begin the test. It will begin to output the voltage. The DANGER indicator lights up and the “Status Line” shows “UNDER TEST” to warn you that it is in a test state and there is voltage output. “Line 2” will show the voltage output reading, “Line 3” will show the reading of capacitance, and “Line 4” performs timing and countdown work.

Note: When testing OSC Mode, Get Cs current range at this time decides the display of capacity effective digit.

Example: Get Cs voltage 0.018kV, Get Cs capacitance value 17.4nF, current=

1.18mA -- at the mass current range
Get Cs voltage 0.016kV, Get Cs capacitance value 17.42nF, current=
0.97mA -- at the medium current range

(5) PASS Judgment

When all test steps are done and the "Status Line" shows PASS, it indicates the DUT is a good product. Then the output is cut off, rear panel outputs the PASS signal and buzzer (short beep) in the meantime.

(6) FAIL Judgment

If the measurement is abnormal, the system will judge the DUT as a failed product and cut off the output. The rear panel outputs a FAIL signal and buzzer (long beep) in the meantime. The action continues until the [STOP] key is pressed. "Status Line" will show the fail state as below. Please see "Description Table for Test Result".

(7) If any errors happen and cause the [START] key to be locked, you can press [STOP] to release it.

(8) You can press the [STOP] key anytime to stop the test output in any case.

■ Description Table for Test Result

Test Result	Meaning
PASS	Passed the tests and judged as a PASS product.
HIGH FAIL	Measurement is over the high limit
LOW FAIL	Measurement is under the low limit
OPEN FAIL	Capacitance open/capacitance reading is lower than the setting of OPEN.
SHORT FAIL	Capacitance short/capacitance reading is higher than the setting of SHORT.
ARC FAIL	The current ARC is over the high limit
I/O FAIL	Hardware detects bad signal. (It may be the short circuit of DUT.)
NO OUTPUT	Output is not enough. (It may be the test time is not enough.)
VOLT OVER	The voltage reading is over the hardware's valid digits.
CURR OVER	The current reading is over the hardware's valid digits.
INRUSH FAIL	The charging current is overly low. (It may be a test fixture bad contact.)
GFI TRIPPED	Grounding failed interrupted
SLAVE FAIL	SLAVE communication fails
SKIPPED	The step is skipped. To skip the step that no need to implement as conducting Get Offset or Get Cs.
Cs/SHORT FAIL	The Cs are too high. To stop the detection of SHORT may resolve this problem.

2.5 Other User Setting Function

2.5.1 KEY LOCK Function

■ Setting KEY LOCK

In **[Standby Menu]**, you can enable the KEY LOCK function if **LOCK** is not highlighted.

- (1) Press Function Key [MENU], use Function Key [F1] and [F2] to move the highlight to "KEY LOCK", and press Function Key [SELECT] to enter into the KEY LOCK setting menu.

KEY LOCK					A
USER PASSWORD:****					B
					ENTER
1-10 CHAR.	RMT	LOCK	OFST	ERR	RETURN

- (2) Use Function Key [A] and [B] to input the PASSWORD (default is AAAA.)
- (3) Press Function Key [ENTER] will prompt a selection window to be highlighted.

KEY LOCK ON !					YES
RECALL LOCK ?					NO
YES/NO	RMT	LOCK	OFST	ERR	CANCEL

- (4) You can press Function Key [YES] or [NO] to select if lock the MEMORY RECALL function as well. Exit the menu after completing the KEY LOCK function and **LOCK** is highlighted in the meantime.
- (5) Press Function Key [CANCEL] to cancel the action and exit the set menu.

■ Canceling KEY LOCK

In **[Standby Menu]**, you can release KEY LOCK if **LOCK** is highlighted. Follow the steps above to cancel KEY LOCK, and **LOCK** will not be highlighted.

2.5.2 Auto Range

- (1) Set WV-AUTO RANGE as ON under the PRESET function list.
- (2) The current set to a high range as below shown.

STEP 1/1 AC	LOW : OFF	PROGRAM
0.050kV	ARC : OFF	PRESET
20.00mA	RAMP : OFF	MENU
3.0s	FALL : OFF	MORE..
STANDBY	RMT	LOCK
OFST	ERR	

- (3) At 0.6 sec before the test ends, if the measured current can be displayed in the low range, it will auto switch to the low range as follows.

STEP 1/1 AC	LOW : OFF	PROGRAM
0.050kV	ARC : OFF	PRESET
0.100mA	PASS	MENU
0.0s	MORE..	
PASS	RMT	LOCK
OFST	ERR	

2.5.3 Change User Password

- (1) In **[Standby Menu]**, press Function Key [MENU], and use Function Key [F1] and [F2] to move the highlight to "CHANGE PASSWORD" and press Function Key [SELECT] to enter into the password menu.

CHANGE PASSWORD	A
USER PASSWORD:****	B
	ENTER
1-10 CHAR.	RETURN
RMT	LOCK
OFST	ERR

- (2) Use Function Key [A] and [B] to input the original PASSWORD (default is AAAA), and press Function Key [ENTER] will show the following "NEW PASSWORD" window.

CHANGE PASSWORD	A
NEW PASSWORD:****	B
	ENTER
1-10 CHAR.	RETURN
RMT	LOCK
OFST	ERR

- (3) Use Function Key [A] and [B] to input the NEW PASSWORD (maximum 10 characters), and press Function Key [ENTER] will display the "CONFIRM" window.

CHANGE USER PASSWORD					A
CONFIRM:					B
					ENTER
1-10 CHAR.		LOCK	OFST		EXIT

- (4) Use Function Key [A] and [B] to input the NEW PASSWORD, and press Function Key [ENTER]. Press [RETURN] after completing the setting.

2.5.4 Remote Control

- **Be aware** when using a remote control by external signal and do not touch the high voltage terminal to avoid causing any danger.
- The REMOTE outlet for the remote control switch is located at the rear panel. You can plug in the control line to use the external signal for controlling the device output externally.
- The remote control is usually done by a high voltage testing bar; however, you can also use other control circuits to do it. Be careful that it is the switch to control high voltage output, so you must connect the control line with caution and not get near the high voltage terminal and test cable to avoid causing any danger.
- For single control of START and RESET signals follow *Figure 2-1* listed below to connect them to the REMOTE position on the system back panel.
- If it is connected as *Figure 2-2* shows, the system routine is in RESET state as the NC is connected to RESET and NO is connected to START.




Figure 2-1




Figure 2-2

- The logic components of the transistor, FET, and couplers can be connected and used as a control circuit. The connected signals and circuit are shown below. To use this circuit to control the system, it must contain the following:

- (1) The current of the LOW signal is 2mA or less.
- (2) The active time for the input signal is more than 20mS.





Figure 2-3

- Either the relay switch control in *Figure 2-1* or the coupler control in



- *Figure 2-3* uses the contact of components for control action. It can prevent the error operation from interference effectively. Though the system has a lot of precautions, you would still need to watch out for the interference caused by the measurement system settings.
- Pin diagram of REMOTE CONTROL as *Figure 2-4*. When the tester is controlled externally, please remember this pin diagram.




Figure 2-4


2.5.5 Output Signal

This instrument has an indicator and beeper for indication signals. The output signals in the system's rear panel are:

- **UNDER TEST:** This terminal will short-circuit when in test mode, thus it can be used to control the external signal. The connecting point specification is 115V AC and the current is less than 0.3A.
- **PASS:** This terminal will short-circuit when the DUT passes the tests, thus it can be used to control the external signal. The connecting point specification is 115V AC and the current is less than 0.3A. The action time from the DUT is passed until it is stopped.

2.5.6 Timing Diagram


(1) Set "END OF STEP" to OFF



Timing diagram – take an example by two test steps

Time	Limit	Description
T1	> 20mS	The remaining time of the external trigger signal (/START). It needs to be over 20mS.
T2	< 200mS	The time of the external trigger signal /START to /UNDER TEST signal to be cleared will be smaller than 200mS. The previous STEP test result /PASS signal status has been cleared in advance.
	< 300mS	The time of the external trigger signal /START to /UNDER TEST signal to be cleared will be smaller than 300mS. The previous STEP test result /PASS signal status hasn't been cleared in advance.
T3	-	Test needed time of various test steps.
T4	> 5mS	/Pass signal sent larger than 5mS, /UNDER TEST signal is end.
T5	-	The equipment used time as testing, the signal is simultaneous with the Danger lamp on the panel.

(2) Set "END OF STEP" to ON



Timing diagram – take an example by two test steps

Time	Limit	Description
T1	> 20mS	The remaining time of the external trigger signal (/START). It needs to be over 20mS.
T2	< 200mS	The time of the external trigger signal /START to /UNDER TEST signal to be cleared will be smaller than 200mS. The previous STEP test result /PASS signal status has been cleared in advance.
	< 300mS	The time of the external trigger signal /START to /UNDER TEST signal to be cleared will be smaller than 300mS. The previous STEP test result /PASS signal status hasn't been cleared in advance.
T3	-	Test needed time of various test steps.
T4	> 5mS	/Pass signal sent larger than 5mS, /UNDER TEST signal is end.
T5	-	The equipment used time as testing, the signal is simultaneous with the Danger lamp on the panel.
T6	>10mS	When the setting of "END OF STEP" is ON, /UNDER TEST signal OFF time is larger than 10mS between STEP and STEP.

3. Installation and Maintenance

3.1 Notices for Installation

This instrument generates a high voltage output of up to 6KV for external tests. Any incorrect or mistaken procedures in using this instrument may cause injury or death. Thus for your safety, be sure to read through the notices described in this chapter and memorize them to prevent any accidents from happening.

- **Induction and electric shock**

To avoid electric shock, we suggest you put on the insulation rubber gloves before performing any electricity-related work.

- **Grounding**

There is a safety grounding terminal at the instrument rear panel. Ensure to use appropriate tools to connect the grounding terminal. If it is not grounding correctly, the chassis of the test machine may contain high voltage when the power circuit or the connecting line of any devices is short-circuited with the grounding terminal. This is very dangerous as it may cause electric shock if anyone touches the instrument under the circumstances. Therefore, it is necessary to connect the safety grounding terminal to the earth correctly. See section 2.2 *Rear Panel* for detailed information.

- **Connecting the test cable to the “Common Test Terminal”**

Please connect the test cable to the “Common Test Terminal” actually. Always check if the test cable is connected properly during the test. When you need to connect the test cable to the unit for the test, use the one on the Common Test Terminal first to connect the DUT. It is very dangerous if the test cable on the Common Test Terminal is not connected completely or is loose as the entire DUT may contain high voltage. Refer to section 2.1 *Front Panel*.

- **Connecting test cable to the “High Voltage Output Terminal”**

Follow the procedures below to connect the high voltage output line after the “Common Test Terminal” is connected.

- Press the [STOP] button first.
- Ensure the DANGER indicator is off.
- Short circuit the “Common Test Terminal” test cable and “High Voltage Output Terminal”, and ensure there is no voltage output.
- Last, connect the “Common Test Terminal” test line to the DUT and then the high voltage test cable to the DUT.
- Plug in the high voltage test cable to the “High Voltage Output Terminal”.

- **End test**


When tests are done and the test instrument is not in use or needs to leave for a while during usage, make sure to turn off the power switch (to O). See section 2.1 *Front Panel* for detailed information.

- **Dangerous places when the instrument is in test mode**

It is very dangerous to touch the area with a high voltage such as the DUT, test cable, probe, and output terminal when the instrument is in test mode.

※ **DO NOT** touch the alligator clip as shown below on the test cable when the system is in test mode as the rubber insulation is not good enough and may cause danger if touched.

Do not touch here when the high voltage outputs.



■ End test confirmation

You may touch the DUT, high voltage test cable, or high voltage output area like the output terminal to alter the layout or perform a particular test request, thus be sure to turn off the power before doing it. For testing the DC HiPot/insulation resistance, the DUT may contain high voltage after completing the test, so you need to carefully follow the instructions described in this chapter to perform the work.

3.1.1 Charging During DC HiPot/Insulation Resistance Test

■ Charge

When doing a DC HiPot/insulation resistance test, the DUT, capacitor, test cable, probe, and an output terminal, even the test instrument may charge with high voltage. The charged voltage may need a period of discharge after the power switch is turned off. Do not touch any places that may cause electric shock as mentioned above, especially at the moment of turning off the power.

■ Confirming the charged voltage is discharged totally

the test voltage applied as well as the DUT characteristics determine the total discharge time for the charged voltage. Assuming the high voltage on the DUT is the voltage plus a 0.01uF capacitor paralleling a 100MΩ resistance circuit, then after turning off the power. The voltage on the test instrument and DUT takes about 3.5 seconds to decrease to 30V. Thus when the test voltage is 500V, it needs about 2.8 seconds. Suppose we already know the time constant of a DUT, you can follow the description above to calculate the time required for voltage decrease to beneath 30V after turning off the power. The method uses the time decreased to under 30V and multiplies the time constant ratio as the figure shown below.




圖 3 - 5

<Formula>

$$\text{Test Voltage} * e^{-t/RC} = \text{Residual Voltage}$$

$$\text{Ex.: } 1000V * e^{-t/RC} = 30V$$

$$\ln^{-t/RC} = \ln 0.03$$

$$-t / RC = -3.5$$

$$t = 3.5 \text{ sec}$$

■ Remote control system

This system is capable of remote control. Usually, it uses an external control signal to do the high voltage output control. For your safety and to prevent accidents, the following principles of control must be performed accurately. Do not allow any unexpected high voltage output to cause any hazards. When the system has a high voltage output, operators and other personnel are not allowed to touch the DUT, test cable probe, output terminal, etc.

■ Turn the power switch on or off ※Attention※

The product should be so positioned that the power switch can be easily reached by the operator during an emergency. Once the power switch is cut off, wait a few seconds to turn it on again. Do not turn on/off the power switch repeatedly to avoid causing any errors. It is very dangerous to do repeating power on/off in a high voltage output state.

The high voltage output terminal cannot connect to any objects during power on or off to avoid hazards caused by abnormal high voltage output.

■ Miscellaneous notices

Do not short-circuit the instrument output line, grounding line, transmission line, or other connector grounding line, and AC source to avoid the entire test device being charged to a very dangerous voltage. To short-circuit the High Voltage Output Terminal and Common Test Terminal, the instrument chassis must be grounded to earth first.

3.1.2 Emergency Events

■ Emergency management

In the emergencies of electric shock, DUT on fire, or system on fire, follow the steps below to avoid causing bigger hazards.

- First, cut off the power switch.
- Then, unplug the power cord.

3.1.3 Solving Problems

■ When problem happens

The problems in the following conditions are very dangerous. The output terminal may still have high voltage output even if the [STOP] button is pressed, so you need to be very careful.

- The DANGER indicator still lights up after the [STOP] button is pressed.
- There is no reading on the voltage meter; however, the DANGER indicator is lit.
When any of the above conditions happens, turn off the power and unplug the AC power cord. Do not use it again as the failure is very dangerous. Send it back to Chroma or the dealer for repair and services.

■ DANGER indicator failure

If you press the [START] button and the voltage meter shows readings but the DANGER indicator is still off, it means the indicator may be failing. Turn the instrument off and replace it immediately, then return the malfunctioning device to Chroma or a dealer for repair and services.

- **Notices when operating the instrument of long duration under normal conditions**
If the high limit is close to the rated value, pay attention to the temperature changes. Stop using it if the ambient temperature is over 40°C. Wait until the temperature is down to normal to resume the operation, and the instrument must be inspected first.
- **There are four types of AC INPUT power sources used in this instrument**
Switch the voltage selector on the rear panel to the correct position according to the voltage used locally. Ensure the AC power source is the same as marked on the power switch located on the rear panel, and the fuse is changed to the appropriate one when plugging in the power cord. The following table lists the fuses for the voltage used:

Center Voltage	Range	Fuse
100V	90V ~ 110V	3.15A Slow/250V
120V	108V ~ 132V	3.15A Slow/250V
220V	198V ~ 242V	1.6A Slow/250V
240V	216V ~ 250V	1.6A Slow/250V

The fuse should conform to the voltage used and replace it when the power cord is unplugged to avoid electric shock. When replacing the fuse, press the fuse holder inside the power socket to remove the existing fuse, insert the new one, and then plug in the power cord.



CAUTION

Be sure to use the correct fuse when changing it, or it may cause danger easily.

- **This instrument operates in an AC power source.**
If the power source is unstable in the range selected, it may cause the instrument to act abnormally or inaccurately. Please use appropriate equipment such as a power regulator to convert it to an applicable power source.
- **This instrument uses a power transformer 200VA or above.**
If the tested device draws a great amount of current, it may flow in the large current (about 10 Ampere) up to 10mS before the judgment of fail and output current cut off. The same situation may occur before performing the test. Thus it is necessary to pay attention to the capacity of the power cord and the current line connected with other instruments and devices.
- **Storage**
The normal temperature range is 18°C~28°C, ≤ 70% RH. The operation may be incorrect if over the range. The storage temperature is -10°C~60°C, ≤ 80% RH. If you are not planning to use it for a long period, pack it with the original box for storage. For the sake of correct test and safety of this instrument, make sure not to store it in a place with direct sunlight or high temperature, also away from shaky, damp, and dusty areas.
- **Warming up**
This instrument activates at power on; however, to meet the accuracy specified in the specification, please warm it up for 15 minutes or above.
- **Warning Signal of Testing**
“DANGER – HIGH VOLTAGE TEST IN PROGRESS, UNAUTHORIZED PERSON KEEP AWAY”

■ Keep the test cable away from the panel

Please keep the high voltage cable or the DUT away from the panel at least 30 cm during operation to avoid the display interference caused by high-voltage discharge.

■ Notices for connecting automated device

- The grounding system of the device and the automated station should be connected.
- Add an anti-interference iron core to the high voltage cable and the 2 ends (device output and DUT) of the RTN/LOW test cable with winding at least 1 circle.
- The high voltage and RTN/LOW test cable must be separate from the control cable.
- The high voltage and RTN/LOW test cable must keep proper distance from the tester panel.

■ Standard warnings

WARNING

1. Only accessories that meet the manufacturer's specifications shall be used.
2. Do not disable the safety purpose of the grounding type plug. Use the power supply cord only in combination with an earthed socket outlet.
3. Do not block any ventilation openings to prevent overheating of the equipment. Keep the ventilation slits uncovered during operation. Failure to do so could cause the instrument to overheat and may damage internal components.
4. The mains plug is used as the disconnecting device and shall remain readily operable. The socket outlet shall be installed near the equipment and shall be easily accessible.
5. If the instrument is used in a matter not specified by the manufacturer, the protection provided by the instrument may be impaired.
6. For European: A certified power supply cord not lighter than light PVC sheathed flexible cord according to IEC 60227, designation H03 VV-F or H03 VVH2-F (for equipment mass not exceeding 3 kg), or H05 VV-F or H05 VVH2-F2 (for equipment mass exceeding 3 kg), and be rated for at least 3G 0.75 mm² (for rated current up to 10 A) or 3G 1.0mm² (for rated current over 10 A up to 16 A) wire or larger, and the length of the cord does not exceed 2 m must be used.

3.2 Notices for Maintenance

Except as notified in the manual the device has no items the user can maintain.

Please contact Chroma or a sales agent when any abnormal condition occurs in this device. Do not perform maintenance by yourself to avoid causing any unnecessary hazards that may damage the device.

3.3 Troubleshooting

Besides replacing the fuse (see section 3.1.3 *Solving Problems*) or other notified in the manual, there is no troubleshooting to be performed by the user.

Please contact Chroma or a sales agent when any abnormal condition occurs in this device. Do not perform maintenance by yourself to avoid causing any unnecessary hazards that may damage the device.

3.4 Input/Output Pin Assignment

See the descriptions of the front panel and rear panel in *Chapter 2*.

4. Calibration Procedure

Before performing this section the HiPot tester must warm up at least for 30 minutes. Take off the calibration label on the front panel and press the lock switch. After completing the calibration, please press the lock switch again to open the hardware data backup protection circuit to avoid calibration data loss.

The following items are required for calibration.

■ Voltage Calibration (See section 4.2)

ACV 5KV Offset (0.05kV)	; AC HiPot Voltage Offset calibration (AC Mode)
ACV 5KV Full (4KV)	; AC HiPot Voltage Full calibration (AC Mode)
DCV 6KV Offset (0.05kV)	; DC HiPot Voltage Offset calibration (DC/IR Mode)
DCV 6KV Full (4KV)	; DC HiPot Voltage Full calibration (DC/IR Mode)
IRV 1KV Offset (0.05kV)	; IR Impedance Voltage Offset calibration (DC/IR Mode)
IRV 1KV Full (1kV)	; IR Impedance Voltage Full calibration (DC/IR Mode)

■ Current Calibration (See section 4.3)

ACA 3mA Offset (0.12mA)	; AC HiPot current 3mA range Offset calibration (AC Mode)
ACA 3mA Full (2.4mA)	; AC HiPot current 3mA range Full calibration (AC Mode)
ACA 20mA Offset (2.4mA)	; AC HiPot current 20mA range Offset calibration (AC Mode)
ACA 20mA Full (12mA)	; AC HiPot current 20mA range Full calibration (AC Mode)
DCA 3mA Offset (0.12mA)	; DC HiPot current 3mA range Offset calibration (DC/IR Mode)
DCA 3mA Full (2.4mA)	; DC HiPot current 3mA range Full calibration (DC/IR Mode)
DCA 5mA Offset (2.4mA)	; DC HiPot current 5mA range Offset calibration (DC/IR Mode)
DCA 5mA Full (4.8mA)	; DC HiPot current 5mA range Full calibration (DC/IR Mode)

■ ARcing Calibration (See section 4.4)

AC ARC 20mA (7mA)	; AC Withstanding Voltage ARcing calibration (AC Mode)
DC ARC 5mA (5mA)	; DC Withstanding Voltage ARcing calibration (DC Mode)

■ Insulation Resistance Calibration (See section 4.5)

IRR Range1 (1000MΩ)	; IR Resistor range 1 calibration (IR Mode)
IRR Range2 (100MΩ)	; IR Resistor range 2 calibration (IR Mode)
IRR Range3 (10MΩ)	; IR Resistor range 3 calibration (IR Mode)
IRR Range4 (10MΩ)	; IR Resistor range 4 calibration (IR Mode)

■ Ground Continue Calibration

GC 5Ω Offset (1Ω)	; GC 5Ω offset calibration
GC 5Ω Full (3Ω)	; GC 5Ω full calibration

■ LCD Contrast Calibration


CAL. CONTRAST (7)	; LCD contrast calibration
-------------------	----------------------------

4.1 Calibration

- Press [MENU].
- Press [UP] or [DOWN] to select "CALIBRATION".
- Press [SELECT].
- Press [A][A][A][B][ENTER].

4.2 Voltage Calibration

4.2.1 Connection Diagram



4.2.2 ACV Calibration (AC Mode)

- (1) Press [UP] or [DOWN] to select ACV offset calibration.
- (2) Connect an AC high voltage meter to the HiPot tester.
- (3) Press [STOP][START]; reading the high voltage meter value, ex. 0.052kV.

ACV 5kV OFFSET (0.05kV)	60Hz	UP
OUTPUT	READING	DOWN
0.050kV	0.050kV	SETUP
STANDARD : 0.052kV		EXIT
[]	[RMT] [LOCK] [OFST] [ERR]	

- (4) Press [INC.] or [DEC.] until the Standard Value displays 0.052 kV and then press [ENTER] for saving.
- (5) Press [STOP] to stop ACV voltage offset calibration.
- (6) Press [UP] to change to the next calibration item.
- (7) Press [STOP][START] to read the high voltage meter value, ex. 4.052kV.

ACV 5kV FULL (4.0kV)		60Hz	UP
OUTPUT	READING		DOWN
4.000kV	4.000kV		SETUP
STANDARD : 4.052kV			EXIT
	RMT	LOCK	OFST
	ERR		

- (8) Press [INC.] or [DEC.] until shows 4.052 kV and press [ENTER] for saving.
- (9) Press [STOP] to stop ACV voltage full-scale calibration.

4.2.3 DCV Calibration (DC/IR MODE)

- (1) Press [UP] or [DOWN] to select DCV offset calibration.
- (2) Connect a DC high voltage meter to the HiPot tester.
- (3) Press [STOP][START] to read the high voltage meter value, ex. 0. 052kV.

DCV 6kV OFFSET (0.05kV)		60Hz	UP
OUTPUT	READING		DOWN
0.050kV	0.050kV		SETUP
STANDARD : 0.052kV			EXIT
	RMT	LOCK	OFST
	ERR		

- (4) Press [INC.][DEC.] until shows 0.052kV and then press [ENTER] for saving.
- (5) Press [STOP] to stop DCV voltage offset calibration.
- (6) Press [UP] to change to the next calibration item.
- (7) Press [STOP][START] to read the high voltage meter value, ex. 4.052kV.

DCV 6kV FULL (4.0kV)		60Hz	UP
OUTPUT	READING		DOWN
4.000kV	4.000kV		SETUP
STANDARD : 4.052kV			EXIT
	RMT	LOCK	OFST
	ERR		

- (8) Press [INC.] or [DEC.] until shows 4.052 kV and then press [ENTER] for saving.
- (9) Press [STOP] to stop DCV voltage full-scale calibration.

4.2.4 IRV Calibration (DC/IR Mode)

- (1) Press [UP] or [DOWN] to select IRV offset calibration.
- (2) Connect a DC high voltage meter to the HiPot tester.
- (3) Press [STOP][START] to read the high voltage meter value, ex. 0.052kV.

IRV 1kV OFFSET (0.05kV)		60Hz	UP
OUTPUT	READING		DOWN
0.050kV	0.050kV		SETUP
STANDARD : 0.052kV			EXIT
	RMT	LOCK	OFST ERR


- (4) Press [INC.] or [DEC.] until shows 0.052 kV and then press [ENTER] for saving.
- (5) Press [STOP] to stop IR voltage offset calibration.
- (6) Press [UP] to change to the next calibration item.
- (7) Press [STOP][START] to read the high voltage meter value, ex. 1.052kV.

IRV 1kV FULL (1.0kV)		60Hz	UP
OUTPUT	READING		DOWN
1.000kV	1.000kV		SETUP
STANDARD : 1.052kV			EXIT
	RMT	LOCK	OFST ERR

- (8) Press [INC.] or [DEC.] until shows 1.052 kV and then press [ENTER] for saving.
- (9) Press [STOP] to stop IR voltage full-scale calibration.

4.3 Current Calibration

4.3.1 Connection Diagram



⚡ CAUTION The dummy load connected to the HiPot terminal contains high voltage. Be very careful with it as it may cause hazards.

4.3.2 ACA Calibration (AC MODE)

- Connect a dummy load resistor 10M Ω , 0.5 Watt or higher to the HiPot tester between the high voltage output terminal and the AC ammeter input high potential terminal. Connect the low potential terminal of the HiPot tester to the low potential terminal of AC ammeter inputting.
 - (1) Press [UP] or [DOWN] to select ACA 3mA range offset calibration.
 - (2) Press [STOP][START] to read the ammeter value, ex. 0.124mA.

ACA 3mA OFFSET (0.12mA)		UP
OUTPUT	READING	DOWN
1.200kV	0.120mA	SETUP
STANDARD : 0.124mA		EXIT
LOAD = 10M Ω	LOCK OFST	

- (3) Press [INC.] or [DEC.] until shows 0.124mA and then press [ENTER] for saving.
- (4) Press [STOP] to stop ACA 3.0mA range offset calibration.
- (5) Press [UP] to change to the next calibration item.
- (6) Change the dummy load resistor to 500k Ω 10watt or higher.
- (7) Press [STOP][START] to read the ammeter value, ex. 2.450mA.

ACV 3mA FULL (2.4mA)		60Hz	UP
OUTPUT	READING		DOWN
1.200kV	2.400mA		SETUP
STANDARD : 2.450kV			EXIT
LOAD=500k Ω	RMT	LOCK	OFST ERR

- (8) Press [INC.] or [DEC.] until shows 2.450mA and then press [ENTER] for saving.
- (9) Press [STOP] to stop ACA 3.0mA range full-scale calibration.
- (10) Press [UP] to change to the next calibration item.
- (11) Press [STOP][START] to read the ammeter value, ex. 2.450mA.

ACA 20mA OFFSET (2.4mA)		60Hz	UP
OUTPUT	READING		DOWN
1.200kV	2.45mA		SETUP
STANDARD : 2.45mA			EXIT
LOAD=500k Ω	RMT	LOCK	OFST ERR

- (12) Press [INC.] or [DEC.] until shows 2.450mA and then press [ENTER] for saving.
- (13) Press [STOP] to stop ACA 20.0mA range offset calibration.
- (14) Press [UP] to change to the next calibration item.
- (15) Change the dummy load resistor to 100k Ω 50watt or higher.
- (16) Press [STOP][START] to read the ammeter value, ex. 12.20mA.

ACA 20mA FULL (12mA)		60Hz	UP
OUTPUT	READING		DOWN
1.200kV	12.00mA		SETUP
STANDARD : 12.20mA			EXIT
LOAD=100k Ω	RMT	LOCK	OFST ERR

- (17) Press [INC.] or [DEC.] until shows 12.20mA and then press [ENTER] for saving.
- (18) Press [STOP] to stop ACA 20.0mA range full-scale calibration.

4.3.3 DCA Calibration (DC/IR MODE)

- Connect a dummy load resistor 10M Ω , 0.5 Watt or higher to the HiPot tester between the high voltage output terminal and the DC ammeter input high potential terminal. Connect

the low potential terminal of the HiPot tester to the low potential terminal of DC ammeter inputting.

- (1) Press [UP] or [DOWN] to select DCA 3mA range offset calibration.
- (2) Press [STOP][START] to read the ammeter value, ex. 0.124mA.

DCA 3mA OFFSET (0.12mA)		60Hz	UP
OUTPUT	READING		DOWN
1.200kV	0.120mA		SETUP
STANDARD : 0.124mA			EXIT
LOAD=10M Ω	RMT	LOCK	OFST ERR

- (3) Press [INC.] or [DEC.] until shows 0.124mA and then press [ENTER] for saving.
- (4) Press [STOP] to stop DCA 3.0mA range offset calibration.
- (5) Press [UP] to change to the next calibration item.
- (6) Change the dummy load resistor to 500k Ω 10watt or higher.
- (7) Press [STOP][START] to read the ammeter value, ex. 2.450mA.


DCV 3mA FULL (2.4mA)		60Hz	UP
OUTPUT	READING		DOWN
1.200kV	2.400mA		SETUP
STANDARD : 2.452mA			EXIT
LOAD=500k Ω	RMT	LOCK	OFST ERR

- (8) Press [INC.] or [DEC.] until shows 2.450mA and then press [ENTER] for saving.
- (9) Press [STOP] to stop DCA 3.0mA range full scale calibration.
- (10) Press [UP] to change to the next calibration item.
- (11) Press [STOP][START] to read the ammeter value, ex. 2.45mA.

DCA 5mA OFFSET (2.4mA)		60Hz	UP
OUTPUT	READING		DOWN
1.200kV	2.40mA		SETUP
STANDARD : 2.45mA			EXIT
LOAD=500k Ω	RMT	LOCK	OFST ERR

- (12) Press [INC.] or [DEC.] until shows 2.45mA and then press [ENTER] for saving.
- (13) Press [STOP] to stop DCA 5.0mA range offset calibration.
- (14) Press [UP] to change to the next calibration item.


- (15) Change the dummy load resistor to 250kΩ 20watt or higher.
- (16) Press [STOP][START] to read the ammeter value, ex. 4.85mA.



- (17) Press [INC.] or [DEC.] until shows 4.85mA and then press [ENTER] for saving.
- (18) Press [STOP] to stop DCA 5.0mA range full-scale calibration.

4.4 ARC Calibration

4.4.1 Connection Diagram



- ⚡ CAUTION**
1. ARC calibration is very special, the high voltage terminals are outside. Be careful with it as it may cause a hazard.
 2. Please contact your local agent for more detailed descriptions.

4.4.2 AC ARC Calibration (AC MODE)

- Connect one terminal of the dummy load resistor 250kΩ, 5 Watt or higher to the high voltage output terminal and get closer to the low potential terminal of the HiPot tester gradually. However, do not connect the HiPot tester to another terminal of the resistor and generate sparking between these two.

- (1) Press [UP] or [DOWN] to select AC ARC calibration.
- (2) Press [SETUP] [READING] to enter the ARC reading setting.
- (3) Press [INC.] or [DEC.] until shows the reading is $(\text{OUTPUT}/\text{READING}) \times 1.414$,

$$((1.25\text{kV}/250\text{k}\Omega)*1.414)=7.7\text{mA}.$$

AC	ARC	20mA	(7mA)	60Hz	UP
OUTPUT		READING			DOWN
1.250kV		7.7mA			SETUP
STANDARD : 7.0mA					EXIT
LOAD=250k Ω		RMT	LOCK	OFST	ERR

- (4) Press [RETURN] twice to exit the ARC reading setting.
- (5) Press [STOP] [START] to start the test.
- (6) Press [INC.] or [DEC.] to adjust the low terminal of the HiPot tester get closer to another terminal of the dummy load resistor gradually, and generate sparking between these two. The HiPot tester happens ARC fail.
- (7) Repeat steps (5) – (6) until the sparking between these two is smaller, the HiPot tester still generates ARC fail.

4.4.3 DC ARC Calibration (DC MODE)


- Connect one terminal of the dummy load resistor 250k Ω , 5 Watt or higher to the high voltage output terminal and get closer to the low potential terminal of the HiPot tester gradually. However, do not connect the HiPot tester to another terminal of the resistor and generate sparking between these two.
- (1) Press [UP] or [DOWN] to select DC ARC calibration.
 - (2) Press [SETUP] [READING] to enter the ARC reading setting.
 - (3) Press [INC.] or [DEC.] until shows the reading is (OUTPUT/READING), (0.75kV/250k Ω) = 3mA.

DC	ARC	5mA	(3mA)	60Hz	UP
OUTPUT		READING			DOWN
0.750kV		3.0mA			SETUP
STANDARD : 3.0mA					EXIT
LOAD=250k Ω		RMT	LOCK	OFST	ERR

- (4) Press [RETURN] twice to exit the ARC reading setting.
- (5) Press [STOP] [START] to start the test.
- (6) Press [INC.] or [DEC.] to adjust the low terminal of the HiPot tester get closer to another terminal of the dummy load resistor gradually, and generate sparking between these two. The HiPot tester happens ARC fail.
- (7) Repeat steps (5) – (6) until the sparking between these two is smaller, the HiPot tester still generates ARC fail.

4.5 IRR Calibration (IR Mode)

4.5.1 Connection Diagram




4.5.2 Insulation Resistance Calibration

- Connecting a standard dummy load resistor between the high voltage output terminal and low potential terminal of the Hi-Pot tester.

IRR Range1 (1000M Ω) ; the dummy load resistor is 1000M Ω .
 IRR Range2 (100M Ω) ; the dummy load resistor is 100M Ω .
 IRR Range3 (10M Ω) ; the dummy load resistor is 10M Ω .
 IRR Range4 (10M Ω) ; the dummy load resistor is 10M Ω .

- Press [UP] or [DOWN] to select IRR range 1 calibration.
- To connect the standard dummy load resistor 1000M Ω .
- Press [STOP] [START].
- Press [INC.] or [DEC.] until shows the standard resistance value, ex. 1000M Ω and then press [ENTER] for saving.



- Press [STOP] to stop IRR range 1 calibration.
- Press [UP] to change to the next calibration item.
- Change the standard dummy load resistor to 100M Ω .
- Press [STOP] [START].
- Press [INC.] or [DEC.] until shows the standard resistance value, ex. 100M Ω and then press [ENTER] for saving.

IRR RANGE2 (100M Ω)		60Hz	UP
OUTPUT	READING		DOWN
0.250kV	100MΩ		SETUP
STANDARD : 100.0M Ω			EXIT
LOAD=100M Ω	RMT	LOCK	OFST ERR

- (10) Press [STOP] to stop IRR range 2 calibration.
 (11) Press [UP] to change to the next calibration item.
 (12) Change the standard dummy load resistor to 10M Ω .
 (13) Press [STOP] [START].
 (14) Press [INC.] or [DEC.] until shows the standard resistance value, ex. 10M Ω and then press [ENTER] for saving.

IRR RANGE3 (10M Ω)		60Hz	UP
OUTPUT	READING		DOWN
0.250kV	10.0MΩ		SETUP
STANDARD : 10.0M Ω			EXIT
LOAD=10M Ω	RMT	LOCK	OFST ERR


- (15) Press [STOP] to stop IRR range 3 calibration.
 (16) Press [UP] to change to the next calibration item.
 (17) Press [STOP] [START].
 (18) Press [INC.] or [DEC.] until shows the standard resistance value, ex. 10M Ω and then press [ENTER] for saving.

IRR RANGE4 (10M Ω)		60Hz	UP
OUTPUT	READING		DOWN
1.000kV	10.0MΩ		SETUP
STANDARD : 10.0M Ω			EXIT
LOAD=10M Ω	RMT	LOCK	OFST ERR

- (19) Press [STOP] to stop IRR range 4 calibration.

4.6 Ground Continuity Calibration

4.6.1 Connection Diagram




4.6.2 Description of Ground Continue Calibration

- Connect the standard dummy load resistor to the rear panel of the HiPot tester which is between the ground continuity current output terminal and the grounding terminal. Using the standard 1Ω and 3Ω 1/8 Watt dummy load resistors.

Prepare a standard 1Ω resistor

- (1) Press [UP].
- (2) Connect the resistor to the ground and CONT.CHK OPTION terminal of rear panel.
- (3) Press [STOP][START] to read GC resistance value 1Ω.
- (4) Press [UP] or [DOWN] until the reading is the actual resistance value.



- (5) Press [ENTER] to save the calibration value.
- (6) Press [STOP] to stop GC 5Ω Offset calibration.

Change the standard resistor to 3Ω.

- (1) Press [UP].
- (2) Connect the resistor to the ground and CONT.CHK OPTION terminal of rear panel.
- (3) Press [STOP][START] to read GC resistance value 3Ω.
- (4) Press [UP] or [DOWN] until the reading is the actual resistance value.

GC 5Ω FULL (3Ω)		60Hz	UP
OUTPUT	READING		DOWN
0.1A	3.0Ω		SETUP
STANDARD : 3.0Ω			EXIT
LOAD=3Ω	RMT	LOCK	OFST ERR

- (5) Press [ENTER] to save the calibration value.
- (6) Press [STOP] to stop GC 5Ω Full calibration.

4.7 LCD Contrast Calibration

- After clearing the memory data, this calibration sets LCD Contrast to the best suitable value.
- (1) Press [UP] or [DOWN] to select LCD Contrast Calibration.
 - (2) Press [SETUP] to enter the LCD Contrast setting.
 - (3) Press [INC.] or [DEC.] until the reading shows the best suitable brightness.

CAL. CONTRAST (7)		60Hz	UP
CONTRAST	CALIBRATION		DOWN
7	12		SETUP
			EXIT
1-15	RMT	LOCK	OFST ERR

4.8 Complete Calibration


- Press [EXIT] to complete the calibration. Press the front panel calibration switch again to open the hardware data backup protection circuit to avoid calibration data loss.

5. RS485 Interface (for Model 19073 + RS485)


If the model 19073 + RS485 is purchased, please refer to this chapter.

5.1 Description of Function

1. RS485 interface can connect multi-device, and it is up to multi-device test synchronously through Master operation.



2. It can connect PC from this interface (PC includes RS485 interface). The PC is instead of Master for up to remote control function.



5.2 Parameter Setting

1. Press [MENU] under [STANDBY] screen, and by using [F1], [F2] to move the highlight to "OPTION" then press [SELECT]. Move the highlight to [REMOTE INTERFACE], press [SELECT] then enter the RS485 setting screen.
2. Use [NEXT] to move the highlight, and [UP], [DOWN] to switch the setting value.
3. Setting item descriptions:
 - a. INTERFACE: It selects if the RS485 interface exists or not.
 - b. UNIT TYPE: It selects the device as Master or Slave.
 - c. BAUD RATE: It selects the transmission rate as 4800, 9600, or 19200 baud rate.
 - d. SLAVE NUMBER (Master Only): When the tester is powered on or the test is completed (selectable), the Master will detect if address 1 to Slave communication is normal or not.
 - e. CHECK RESULT (Master Only): When CHECK RESULT ON, the rear panel signal

meanings of Master are as follows:

UNDER TEST signal: It means Slave in testing.

PASS signal: It means all Slave connections are normal and the test is completed.

FAIL signal: It means the Slave does not complete the test, maybe the connections are abnormal.

Notice When CHECK RESULT ON, Master will not judge the test result of the DUT, thus Master cannot connect the DUT.


4. SEND START (Master Only): It controls that Master receives [START] signal of the front panel or rear panel if sending the signal to all Slaves through the RS485 interface.

Notice When the tester power-on, before testing if Slave communication is normal, the Master will switch the Slave to Remote status in advance. When the test is completed, if this switch (SEND START) is set as OFF then Master will switch Slave to Local status.

5. UNIT ADDRESS (Slave Only): It sets the Slave address, the range is 1-31 (Master address is fixed on 32).


5.3 Terminal and Pin Signal Connection

RS485




5.4 Communication Protocol


This interface uses a half-duplex of 2-wire system non-synchronized transmission mode.



Before the bus control is transferred, please wait for the time of two characters.



The transmission format of the character is 1 initial bit, 8 data bits, and 1 end bit, the total is 10 bits.



The receivers do not respond to any data under broadcast mode. When the receivers receive the query functions under node-to-node transmission mode, it returns the relative data. However, when the receivers receive the execution command, it returns the result of the execution. About the Reply Message, please refer to the descriptions of the command.

The commands are packed into packets. The Data Frame is as follows:

Header	DA	SA	Length	Data Field	Checksum
1 byte	1 byte	1 byte	1 byte	n bytes	1 byte

Header: 0xAB
 Destination Address: 0x0 ~ 0x7F, 0xFF is broadcast address
 Source Address: 0x0 ~ 0x7F
 Data Length: It means the length of the data field.
 Data Field: Please refer to the command set.

Command Code	Parameter
1 byte	0 ~ n-1 bytes

Checksum: Summing these values into two complements, included data are DA + SA + Length + Data Field

5.5 Commands List

Commands	Code (Hex)
*IDN?	0x90
Display Address	0x20
Stop	0x21
Start	0x22
Offset Get/Off	0x23
Offset?	0xA3
Step Parameters	0x24
Step Parameters?	0xA4
Preset Parameters	0x25
Preset Parameters	0xA5
Store Memory	0x26
Recall Memory	0x27
Delete Memory	0x28
System Setting	0x29
System Setting?	0xA9
Key Lock	0x2A
Key Lock?	0xAA
Initialize All Steps Parameters	0x2C
Step Number?	0xAD
Remote/Local	0x2E
Remote?	0xAE
Set C Standard	0x2F
Result?	0xB1
Do Get C Standard	0x33
Reply Message	0x7F

5.6 Command Description

*IDN?

Description:	It queries the devices' identification and describes the string.
Command code:	0x90
Parameter:	None
Return data:	The format is "Company Name, Device Name, Device S/N, Firmware Version, Hold Field"
Example:	
Master (0x70):	0xAB 0x01 0x70 0x01 0x90 0xFE
Slave (0x01):	0xAB 0x70 0x01 0x16 0x90 0x43 0x48 0x52 0x4F 0x4D 0x41 0x2C 0x31 0x39 0x30 0x37 0x33 0x2C 0x30 0x2C 0x33 0x2E 0x31 0x31 0x2C 0x30 0x58

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
 0x01 = Destination Address
 0x70 = Source Address
 0x01 = Data Length
 0x90 = Command Code
 0xFE = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
0x70 = Destination Address
0x01 = Source Address
0x16 = Data Length
0x90 = Command Code
0x43 0x48 0x52 0x4F 0x4E 0x4D 0x41 = "CHROMA" Company Name (return data)
0x2C = "," (return data)
0x31 0x39 0x30 0x37 0x33 = "19073" Device Name (return data)
0x2C = "," (return data)
0x30 = "0" Device S/N (return data) (It is not 0 when there is a serial number.)
0x2C = "," (return data)
0x33 0x2E 0x31 0x31 = "3.11" Firmware Version (return data)
0x2C = "," (return data)
0x30 = "0" Hold Field (return data)
0x58 = Checksum

Display Address

Description: It displays the device address.
Command code: 0x20
Parameter: None
Return data: Reply Message
Example: Master (0x70): 0xAB 0x01 0x70 0x01 0x20 0x6E
Slave (0x01): 0xAB 0x70 0x01 0x02 0x7F 0x00 0x0E

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
0x01 = Destination Address
0x70 = Source Address
0x01 = Source Address
0x20 = Command Code
0x6E = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
0x70 = Destination Address
0x01 = Source Address
0x02 = Source Address
0x7F = Reply Message Command Code
0x00 = Reply Message Return Data
0x0E = Checksum

Stop

Description: Stop the test.
Command code: 0x21
Parameter: None
Return data: Reply Message
Example: Master (0x70): 0xAB 0x01 0x70 0x01 0x21 0x6D
Slave (0x01): 0xAB 0x70 0x01 0x02 0x7F 0x00 0x0E

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
 0x01 = Destination Address
 0x70 = Source Address
 0x01 = Data Length
 0x21 = Command Code
 0x6D = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
 0x70 = Destination Address
 0x01 = Source Address
 0x02 = Data Length
 0x7F = Reply Message Command Code
 0x00 = Reply Message Return Data
 0x0E = Checksum

Start

Description:	Start test
Command code:	0x22
Parameter:	None
Return data:	Reply Message
Example:	Master (0x70): 0xAB 0x01 0x70 0x01 0x22 0x6C Slave (0x01): 0xAB 0x70 0x01 0x02 0x7F 0x00 0x0E

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
 0x01 = Destination Address
 0x70 = Source Address
 0x01 = Data Length
 0x22 = Command Code
 0x6C = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
 0x70 = Destination Address
 0x01 = Source Address
 0x02 = Data Length
 0x7F = Reply Message Command Code
 0x00 = Reply Message Return Data
 0x0E = Checksum

Offset Get/Off

Description:	It switches OFFSET status.
Command code:	0x23
Parameter:	1 byte, 0: OFF or 2: GET
Return data:	Reply Message
Example:	Master (0x70): 0xAB 0x01 0x70 0x02 0x23 0x02 0x68 Slave (0x01): 0xAB 0x70 0x01 0x02 0x7F 0x00 0x0E

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
0x01 = Destination Address
0x70 = Source Address
0x02 = Data Length
0x23 = Command Code
0x02 = 2: GET (Command Parameter)
0x68 = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
0x70 = Destination Address
0x01 = Source Address
0x02 = Data Length
0x7F = Reply Message Command Code
0x00 = Reply Message Return Data
0x0E = Checksum

Offset?

Description: It queries OFFSET status.
Command code: 0xA3
Parameter: None
Return data: 1 byte, 0: Off, 1: On or 2: Getting
Example: Master (0x70): 0xAB 0x01 0x70 0x01 0xA3 0xEB
Slave (0x01): 0xAB 0x70 0x01 0x02 0xA3 0x00 0xEA

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
0x01 = Destination Address
0x70 = Source Address
0x01 = Data Length
0xA3 = Command Code
0xEB = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
0x70 = Destination Address
0x01 = Source Address
0x02 = Data Length
0xA3 = Command Code
0x00 = 0: Off (Return Data)
0xEA = Checksum

Step Parameters

Description: It sets all parameters of various steps.
Command code: 0x24
Parameter: 28 bytes

AC mode

Name	Size (byte)	Unit	Range	Description
Step index	1	-	1~10	Must less or equal original step number + 1
Mode	1	-	1	AC mode
Source	2	V	0, 50~5000	0:OFF
Ramp Time	2	100mS	0~9990	0:OFF
Reserved	2	-	0	Reserved
Test Time	2	100mS	0~9990	0:Continue
Fall Time	2	100mS	0~9990	0:OFF
High Limit	4	100nA	10~200000 10~30000	The max. is 200000 when EN50191 is OFF. The max. is 30000 when EN50191 is ON.
Low Limit	4	100nA	0, 10~200000 10~30000	0:OFF The max. is 200000 when EN50191 is OFF. The max. is 30000 when EN50191 is ON.
Arc Limit	4	100nA	0, 10000~200000	0:OFF
Reserved	4	-	0	Reserved

DC Mode

Name	Size (byte)	Unit	Range	Description
Step index	1	-	1~10	Must less or equal original step number + 1
Mode	1	-	2	DC mode
Source	2	V	0, 50~6000	
Ramp Time	2	100mS	0~9990	0:OFF
Dwell Time	2	100mS	0~9990	0:OFF
Test Time	2	100mS	0~9990	0:Continue
Fall Time	2	100mS	0~9990	0:OFF
High Limit	4	100nA	1~50000	
Low Limit	4	100nA	0~50000	0:OFF
Arc Limit	4	100nA	0, 10000~50000	0:OFF
Inrush	4	-	0/10000	0:OFF, 10000:ON

IR Mode

Name	Size (byte)	Unit	Range	Description
Step index	1	-	1~10	Must less or equal original step number + 1
Mode	1	-	3	IR mode
Source	2	V	0, 50~1000	
Ramp Time	2	100mS	0~9990	0:OFF
Dwell Time	2	100mS	0~9990	0:OFF
Test Time	2	100mS	0, 3~9990	0:Continue
Fall Time	2	100mS	0~9990	0:OFF
High Limit	4	100kOhm	0~500000	0:OFF
Low Limit	4	100kOhm	1~500000	
IR Range	4	-	0~6	0: 300nA, 1: 3uA, 2: 30uA, 3: 300uA, 4: 3mA, 5: 5mA, 6: Auto Range
Reserved	4	-	0	Reserved

GC Mode

Name	Size (byte)	Unit	Range	Description
Step index	1	-	1~10	Must less or equal original step number + 1
Mode	1	-	4	GC mode
Source	2	100mA	0/1	
Reserved	2	-	0	Reserved
Dwell Time	2	100mS	1~10	
Reserved	2	-	0	Reserved
Reserved	2	-	0	Reserved

Name	Size (byte)	Unit	Range	Description
High Limit	4	100mOhm	1~50	
Low Limit	4	100mOhm	0~50	0:OFF
Reserved	4	-	0	Reserved
Reserved	4	-	0	Reserved

PA Mode (Pause mode)

Name	Size (byte)	Unit	Range	Description
Step index	1	-	1~10	Must less or equal original step number + 1
Mode	1	-	5	PA mode
UT Signal	2	-	1 or 2	(Under Test Signal) 1:Off, 2:On
Message	16	-		C String, maximum length is 15
Reserved	4	-	0	Reserved
Reserved	4	-	0	Reserved

OS Mode (OSC mode)

Name	Size (byte)	Unit	Range	Description
Step index	1	-	1~10	Must less or equal original step number + 1
Mode	1	-	6	OS mode
Source	2	V	100	Always 100V
Open Limit	2	10%	1~10	10% ~ 100%
Reserved	2	-	0	Reserved
Test Time	2	100mS	1	Always 100mS
Short Limit	2	100%	0, 1~5	OFF, 100% ~ 500%
C Standard	4	pF	0~25100 0~5000	When Short Limit is OFF, Max. is 25100. When Short Limit is not OFF, Max. is 5000.
Reserved	4	-	0	Reserved
Range	4	-	1~3	3 is the maximum range
Reserved	4	-	0	Reserved

Return data: Reply Message

Example: Master (0x70): 0xAB 0x01 0x70 0x1D 0x24 0x01 0x01 0xE8 0x03
0x14 0x00 0x00 0x00 0x32 0x00 0x1E 0x00 0x10 0x27 0x00 0x00
0xE8 0x03 0x00 0x00 0x10 0x27 0x00 0x00 0x00 0x00 0x00 0x00
0xA4
Slave (0x01): 0xAB 0x70 0x01 0x02 0x7F 0x00 0x0E

Remark:

1. When the length of data is larger than 1 character (byte), it is needed to send the minimum character in advance.
2. When the message in PA mode is a lowercase character, it will change to an uppercase character automatically.
3. The inputted various parameters will round off automatically and then save to memory as needed.

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header

0x01 = Destination Address

0x70 = Source Address

0x1D = Data Length

0x24 = Command Code

0x01 = Step1 (Command Parameter)

0x01 = AC Mode (Command Parameter)

0xE8 0x03 = Voltage 1000V (Command Parameter)

0x14 0x00 = Ramp Time 2sec (Command Parameter)
0x00 0x00 = Reserved (Command Parameter)
0x32 0x00 = Test Time 5sec (Command Parameter)
0x1E 0x00 = Fall Time 3sec (Command Parameter)
0x10 0x27 0x00 0x00 = Hi Limit 1.000mA (Command Parameter)
0xE8 0x03 0x00 0x00 = Low Limit 0.100mA (Command Parameter)
0x10 0x27 0x00 0x00 = Arc Limit 1.000mA (Command Parameter)
0x00 0x00 0x00 0x00 = Reserved (Command Parameter)
0xA4 = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
0x70 = Destination Address
0x01 = Source Address
0x02 = Data Length
0x7F = Reply Message Command Code
0x00 = Reply Message Return Data
0x0E = Checksum

Step Parameters?

Description: It queries all parameters of various steps.
Command code: 0xA4
Parameter: 1 byte, the serial number of step, the range is 1-10.
Return data: 28 bytes of data
Example: Master (0x70): 0xAB 0x01 0x70 0x02 0xA4 0x01 0xE8
Slave (0x01): 0xAB 0x70 0x01 0x1D 0xA4 0x01 0x01 0x38 0x04
0x1E 0x00 0x00 0x00 0x3C 0x00 0x09 0x00 0x0C
0x17 0x00 0x00 0x90 0x01 0x00 0x00 0x20 0x4E
0x00 0x00 0x00 0x00 0x00 0x00 0x0B

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
0x01 = Destination Address
0x70 = Source Address
0x02 = Data Length
0xA4 = Command Code
0x01 = Parameter
0xE8 = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
0x70 = Destination Address
0x01 = Source Address
0x1D = Data Length
0xA4 = Command Code
0x01 = Step1 (Return Data)
0x01 = AC Mode (Return Data)
0x38 0xE4 = Voltage 1080V (Return Data)
0x1E 0x00 = Ramp Time 3sec (Return Data)
0x00 0x00 = Reserved (Return Data)
0x3C 0x00 = Test Time 6sec (Return Data)
0x09 0x00 = Fall Time 0.9sec (Return Data)

0x0C 0x17 0x00 0x00 = Hi Limit 0.590mA (Return Data)
 0x90 0x01 0x00 0x00 = Low Limit 0.040mA (Return Data)
 0x20 0x4E 0x00 0x00 = Arc Limit 2.000mA (Return Data)
 0x00 0x00 0x00 0x00 = Reserved (Return Data)
 0x0B = Checksum

Preset Parameters

Description: It sets all parameters of Preset.

Command code: 0x25

Parameter: 6 bytes

Name	Size (byte)	Unit	Range	Description
AC Frequency	1	Hz	50/60	
Software AGC	1	-	0/1	0:OFF, 1:ON
WV Auto Range	1	-	0/1	0:OFF, 1:ON
IR Auto Range	1	-	0/1	0:OFF, 1:ON
GFI(Ground Fault Interrupt)	1	-	0/1	0:OFF, 1:ON
Fail Restart	1	-	0/1	0:OFF, 1:ON
Screen	1	-	0/1	0:OFF, 1:ON

Return data: Reply Message

Example: Master (0x70): 0xAB 0x01 0x70 0x08 0x25 0x32 0x00 0x01 0x00 0x01
 0x01 0x00 0x2D

Slave (0x01): 0xAB 0x70 0x01 0x02 0x7F 0x00 0x0E

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header

0x01 = Destination Address

0x70 = Source Address

0x08 = Data Length

0x25 = Command Code

0x32 = ACV Frequency 50Hz

0x00 = Software AGC OFF

0x01 = WV Auto Range ON

0x00 = IR Auto Range OFF

0x01 = Ground Fault Interrupt (GFI) ON

0x01 = Fail Restart ON

0x00 = Screen OFF

0x2D = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header

0x70 = Destination Address

0x01 = Source Address

0x02 = Data Length

0x7F = Reply Message Command Code

0x00 = Reply Message Return Data

0x0E = Checksum

Preset Parameter?

Description:	It queries all parameters of Preset.
Command code:	0xA5
Parameter:	None
Return data:	6 bytes
Example:	Master (0x70): 0xAB 0x01 0x70 0x01 0xA5 0xE9 Slave (0x01): 0xAB 0x70 0x01 0x08 0xA5 0x3C 0x01 0x00 0x01 0x01 0x00 0x01 0xA2

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
0x01 = Destination Address
0x70 = Source Address
0x01 = Data Length
0xA5 = Data Length
0xE9 = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
0x70 = Destination Address
0x01 = Source Address
0x07 = Data Length
0xA5 = Command Code
0x3C = ACV Frequency 60Hz (Return Data)
0x01 = Software AGC ON (Return Data)
0x00 = WV Auto Range OFF (Return Data)
0x01 = IR Auto Range ON (Return Data)
0x01 = Ground Fault Interrupt (GFI) ON
0x00 = Fail Restart OFF (Return Data)
0x01 = Screen ON
0xA2 = Checksum

Store Memory

Description:	It saves the parameters of various steps and Preset to the internal memory.
Command code:	0x26
Parameter:	Serial number of memory + Name of memory. The length of a serial number of memory is 1 character. The range is 1 ~ 60, and the name length of the memory is 0 ~ 10 characters.
Return data:	Reply Message
Example:	Master (0x70): 0xAB 0x01 0x70 0x08 0x26 0x01 0x43 0x48 0x52 0x4F 0x4D 0x41 0xA6 Slave (0x01): 0xAB 0x70 0x01 0x02 0x7F 0x00 0x0E
Remark:	When the name of memory is a lowercase character, it will change to the uppercase character automatically.

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
0x01 = Destination Address
0x70 = Source Address
0x08 = Data Length (Length of memory name is 6)

0x26 = Command Code
0x01 = Memory S/N

0x43 0x48 0x52 0x4F 0x4D 0x41 = "CHROMA" Memory Name
(Command Parameter)
0xA6 = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
0x70 = Destination Address
0x01 = Source Address
0x02 = Data Length
0x7F = Reply Message Command Code
0x00 = Reply Message Return Data
0x0E = Checksum

Recall Memory

Description:	It recalls the saved test steps from various device internal memories.
Command code:	0x27
Parameter:	1 byte, serial number of memory, the range is 1 ~ 60
Return data:	Reply Message
Example:	Master (0x70): 0xAB 0x01 0x70 0x02 0x27 0x01 0x65 Slave (0x01): 0xAB 0x70 0x01 0x02 0x7F 0x00 0x0E

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
0x01 = Destination Address
0x70 = Source Address
0x02 = Data Length
0x27 = Command Code
0x01 = "01" Memory S/N (Command Parameter)
0x65 = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
0x70 = Destination Address
0x01 = Source Address
0x02 = Data Length
0x7F = Reply Message Command Code
0x00 = Reply Message Return Data
0x0E = Checksum

Delete Memory

Description:	It deletes the saved test steps from the memories inside the device.
Command code:	0x28
Parameter:	1 byte, serial number of memory, the range is 0 ~ 60. When the parameter is 0, it means it needs to clear the working memory which includes all steps and Preset parameters.
Return data:	Reply Message
Example:	Master (0x70): 0xAB 0x01 0x70 0x02 0x28 0x01 0x64 Slave (0x01): 0xAB 0x70 0x01 0x02 0x7F 0x00 0x0E

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
 0x01 = Destination Address
 0x70 = Source Address
 0x02 = Data Length
 0x28 = Command Code
 0x01 = "01" Memory S/N (Command Parameter)
 0x64 = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
 0x70 = Destination Address
 0x01 = Source Address
 0x02 = Data Length
 0x7F = Reply Message Command Code
 0x00 = Reply Message Return Data
 0x0E = Checksum

System Setting

Description: It sets the system parameter.

Command code: 0x29

Parameter: 4 bytes

Name	Size (byte)	Unit	Range	Description
Contrast	1	-	1~15	
Buzzer Volume	1	-	0/1/2/3	0: OFF, 1: Low, 2: Medium, 3: High
EN50191	1	-	0/1	0: OFF, 1: ON (AC maximum is 3mA)
DC 50V AGC	1	-	0/1	0: OFF, 1: ON
Pass On	1	100mS	0 ~ 100	0: OFF
END OF STEP	1	-	0/1	0: OFF, 1: ON
EOT	1	-	0/1	0: END OF TEST, 1: END OF TIMER

Return data: Reply Message

Example: Master (0x70): 0xAB 0x01 0x70 0x08 0x29 0x0A 0x03 0x00 0x00
 0x00 0x00 0x01 0x50
 Slave (0x01): 0xAB 0x70 0x01 0x02 0x7F 0x00 0x0E

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
 0x01 = Destination Address
 0x70 = Source Address
 0x08 = Data Length
 0x29 = Command Code
 0x0A = Contrast 10 (Command Parameter)
 0x03 = Buzzer Volume High (Command Parameter)
 0x00 = EN50191 OFF (Command Parameter)
 0x00 = DC 50V AGC OFF (Command Parameter)
 0x00 = PASS ON OFF (Command Parameter)
 0x00 = END OF STEP OFF (Command Parameter)
 0x01 = END OF TIMER (Command Parameter)

0x50 = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header

0x70 = Destination Address

0x01 = Source Address

0x02 = Data Length

0x7F = Reply Message Command Code

0x00 = Reply Message Return Data

0x0E = Checksum

System Setting?

Description: It queries the system parameter.

Command code: 0xA9

Parameter: None

Return data: 7 bytes

Example: Master (0x70): 0xAB 0x01 0x70 0x01 0xA9 0xE5

Slave (0x01): 0xAB 0x70 0x01 0x08 0xA9 0x08 0x01 0x01 0x01
0x00 0x00 0x01 0xD2

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header

0x01 = Destination Address

0x70 = Source Address

0x01 = Data Length

0xA9 = Command Code

0xE5 = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header

0x70 = Destination Address

0x01 = Source Address

0x08 = Data Length

0xA9 = Command Code

0x08 = Contrast 8 (Return Data)

0x01 = Buzzer Volume Low (Return Data)

0x01 = EN50191 ON (Return Data)

0x01 = DC 50V AGC ON (Return Data)

0x00 = PASS ON OFF (Command Parameter)

0x00 = END OF STEP OFF (Command Parameter)

0x01 = END OF TIMER (Command Parameter)

0xD2 = Checksum

InterLock?

Description: It queries the INTERLOCK status.

Command code: 0xB0

Parameter: None

Return data: 1 byte

0: No InterLock

1: With InterLock

Example: Master (0x70): 0xAB 0x01 0x70 0x01 0xB0 0xDE

Slave (0x01): 0xAB 0x70 0x01 0x02 0xB0 0x01 0xDC

Example description:

The meanings of the 16-bit input settings are as follows:

0xAB = Header
 0x01 = Destination Address
 0x70 = Source Address
 0x01 = Data Length
 0xB0 = Command Code
 0xDE = Checksum

The meanings of the 16-bit return codes are as follows:

0xAB = Header
 0x70 = Destination Address
 0x01 = Source Address
 0x02 = Data Length
 0xB0 = Command Code
 0x01 = "01"InterLock ON (return data)
 0xDC = Checksum

Key Lock

Description:	It switches KEY LOCK status.
Command code:	0x2A
Parameter:	1 byte
	0: keyboard lock OFF, recall key lock OFF
	1: Keyboard lock ON, recall key lock OFF
	2: keyboard lock ON, recall key lock ON
Return data:	Reply Message
Example:	Master (0x70): 0xAB 0x01 0x70 0x02 0x2A 0x01 0x62
	Slave (0x01): 0xAB 0x70 0x01 0x02 0x7F 0x00 0x0E

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
 0x01 = Destination Address
 0x70 = Source Address
 0x02 = Data Length
 0x2A = Command Code
 0x01 = "01" keyboard lock ON, recall key lock (Command Parameter)
 0x62 = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
 0x70 = Destination Address
 0x01 = Source Address
 0x02 = Data Length
 0x7F = Reply Message Command Code
 0x00 = Reply Message Return Data
 0x0E = Checksum

Key Lock?

Description:	It queries KEY LOCK status.
Command code:	0xAA
Parameter:	None
Return data:	1-byte data

0: keyboard lock OFF, recall key lock OFF
1: Keyboard lock ON, recall key lock OFF
2: keyboard lock ON, recall key lock ON
Example: Master (0x70): 0xAB 0x01 0x70 0x01 0xAA 0xE4
Slave (0x01): 0xAB 0x70 0x01 0x02 0xAA 0x01 0xE2

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
0x01 = Destination Address
0x70 = Source Address
0x01 = Data Length
0xAA = Command Code
0xE4 = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
0x70 = Destination Address
0x01 = Source Address
0x02 = Data Length
0xAA = Command Code
0x01 = "01" Keyboard Lock ON, Recall Key Lock OFF (Return Data)
0xE2 = Checksum

Initialize All Steps Parameters

Description: It sets all steps to the initial setting, this command will delete all steps.
Command code: 0x2C
Parameter: None
Return data: Reply Message
Example: Master (0x70): 0xAB 0x01 0x70 0x01 0x2C 0x62
Slave (0x01): 0xAB 0x70 0x01 0x02 0x7F 0x00 0x0E

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
0x01 = Destination Address
0x70 = Source Address
0x01 = Data Length
0x2C = Command Code
0x62 = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
0x70 = Destination Address
0x01 = Source Address
0x02 = Data Length
0x7F = Reply Message Command Code
0x00 = Reply Message Return Data
0x0E = Checksum

Step Number?

Description: It queries the step numbers of being set.

Command code: 0xAD
Parameter: None
Return data: 1-byte data
Example: Master (0x70): 0xAB 0x01 0x70 0x01 0xAD 0xE1
Slave (0x01): 0xAB 0x70 0x01 0x02 0xAD 0x05 0xDB

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
0x01 = Destination Address
0x70 = Source Address
0x01 = Data Length
0xAD = Command Code
0xE1 = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
0x70 = Destination Address
0x01 = Source Address
0x02 = Data Length
0xAD = Command Code
0x05 = "05" the step numbers of being set (Return Data)
0xDB = Checksum

Remote/Local

Description: It switches the device to remote or local control.
Command code: 0x2E
Parameter: 1 byte
0: Go to Local.
1: Go to Remote.
2: Go to Remote and Local Lockout
Return data: Reply Message
Example: Master (0x70): 0xAB 0x01 0x70 0x02 0x2E 0x01 0x5E
Slave (0x01): 0xAB 0x70 0x01 0x02 0x7F 0x00 0x0E

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
0x01 = Destination Address
0x70 = Source Address
0x02 = Data Length
0x2E = Command Code
0x01 = "1" Go to Remote (Command Parameter)
0x5E = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
0x70 = Destination Address
0x01 = Source Address
0x02 = Data Length
0x7F = Reply Message Command Code
0x00 = Reply Message Return Data
0x0E = Checksum

Remote Status?

Description: It queries the remote status of the device.
 Command code: 0xAE
 Parameter: None
 Return data: 1-byte data
 0: Local
 1: Remote
 2: Remote and Local Lockout
 Example: Master (0x70): 0xAB 0x01 0x70 0x01 0xAE 0xE0
 Slave (0x01): 0xAB 0x70 0x01 0x02 0xAE 0x01 0xDE

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
 0x01 = Destination Address
 0x70 = Source Address
 0x01 = Data Length
 0xAE = Command Code
 0xE0 = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
 0x70 = Destination Address
 0x01 = Source Address
 0x02 = Data Length
 0xAE = Command Code
 0x01 = "1" Remote (Return Data)
 0xDE = Checksum

Set C Standard

Description: It sets the standard capacitance of OS mode.
 Command code: 0x2F
 Parameter: 6 byte

Name	Size (byte)	Unit	Range	Description
Step Index	1	-	1~10	
C Standard	4	pF	0~25100 0~5000	When the Short Limit is OFF, Max. is 25100. When the Short Limit is not OFF, Max. is 5000.
Range	1	-	1~3	3 is the maximum range

Return data: Reply Message
 Example: Master (0x70): 0xAB 0x01 0x70 0x07 0x2F 0x01 0x00 0x04 0x00
 0x00 0x01 0x53
 Slave (0x01): 0xAB 0x70 0x01 0x02 0x7F 0x00 0x0E

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
 0x01 = Destination Address
 0x70 = Source Address
 0x07 = Data Length
 0x2F = Command Code

0x01 = Step Index 1(setting data)
 0x00 0x04 0x00 0x00 = C Standard 1024pF (setting data)
 0x01 = Range 1(setting data)
 0x53 = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
 0x70 = Destination Address
 0x01 = Source Address
 0x02 = Data Length
 0x7F = Reply Message Command Code
 0x00 = Reply Message Return Data
 0x0E = Checksum

Result?

Description: It queries the test result and measurement value.
 Command code: 0xB1
 Parameter: 2 bytes, serial numbers of steps + items of measurement values, the range of serial numbers of steps is 0 ~ 10. When the range is 0, it means to query the last one that starts to perform or the step that is performed completely. According to the weight of 2 to divide the measurement value option into 8 items, if queries multi-item simultaneously, the lesser weight is sent at first.
 The measurement value option:

AC mode

Item Number	Name	Size (byte)	Unit	Description
1	Mode	1	-	1:AC Mode
2	Meter 1 (Source)	2	V	30000: Maximum, 31000: Not Value
4	Meter 2 (Current)	4	100nA	1000000000: Maximum, 1100000000: Not Value
8	Meter 3	4	-	Reserved
16	Ramp Time	2	100mS	30000: Maximum, 31000: Not Value
32	Reserved	2	-	Reserved
64	Test Time	2	100mS	30000: Maximum, 31000: Not Value
128	Fall Time	2	100mS	30000: Maximum, 31000: Not Value

DC mode

Item Number	Name	Size (byte)	Unit	Description
1	Mode	1	-	2:DC Mode
2	Meter 1 (Source)	2	V	30000: Maximum, 31000: Not Value
4	Meter 2 (Current)	4	100nA	1000000000: Maximum, 1100000000: Not Value
8	Meter 3 (Inrush)	4	100nA	1000000000: Maximum, 1100000000: Not Value
16	Ramp Time	2	100mS	30000: Maximum, 31000: Not Value
32	Dwell Time	2	100mS	30000: Maximum, 31000: Not Value
64	Test Time	2	100mS	30000: Maximum, 31000: Not Value
128	Fall Time	2	100mS	30000: Maximum, 31000: Not Value

IR mode

Item Number	Name	Size (byte)	Unit	Description
1	Mode	1	-	3:IR Mode
2	Meter 1 (Source)	2	V	30000: Maximum, 31000: Not Value
4	Meter 2 (Resistance)	4	100kOhm	1000000000: Maximum, 1100000000: Not Value
8	Meter 3	4	-	Reserved
16	Ramp Time	2	100mS	30000: Maximum, 31000: Not Value

32	Dwell Time	2	100mS	30000: Maximum, 31000: Not Value
64	Test Time	2	100mS	30000: Maximum, 31000: Not Value
128	Fall Time	2	100mS	30000: Maximum, 31000: Not Value

GC mode

Item Number	Name	Size (byte)	Unit	Description
1	Mode	1	-	4:GC Mode
2	Meter 1 (Source)	2	mA	30000: Maximum, 31000: Not Value
4	Meter 2 (Resistance)	4	100mOhm	10000000000: Maximum, 11000000000: Not Value
8	Meter 3	4	-	Reserved
16	Reserved	2	-	Reserved
32	Dwell Time	2	100mS	30000: Maximum, 31000: Not Value
64	Reserved	2	-	Reserved
128	Reserved	2	-	Reserved

PA mode

Item Number	Name	Size (byte)	Unit	Description
1	Mode	1	-	5:PA Mode
2	Under Test Signal	2	-	1:Off, 2:On
4, 8, 16, 32, 64 or 128	Message	16	-	C String, the maximum length is 15

OS mode

Item Number	Name	Size (byte)	Unit	Description
1	Mode	1	-	6:OS Mode
2	Meter 1 (Source)	2	V	30000: Maximum, 31000: Not Value
4	Meter 2 (capacitance)	4	pF	10000000000: Maximum, 11000000000: Not Value
8	Reserved	4	-	Reserved
16	Reserved	2	-	Reserved
32	Reserved	2	-	Reserved
64	Test Time	2	100mS	30000: Maximum, 31000: Not Value
128	Reserved	2	-	Reserved

Return data: The flag of new test result (1 byte) + serial number of step (1 byte) + test result (1 byte) + measurement value option (1 byte) [+ measurement value 1 + measurement value 2 + ...]

The flag is with the new test result: it is the correct flag that can judge the measurement result. This flag is set to ON when the test is initiated, and set to OFF when the test is stopped. Alternatively, the test is ended and the result is read by this command, then set as OFF. Thus, only in the test duration, the test completed or uses this command to read the first time, this flag is ON otherwise is OFF.

Return test result codes:

Mode	AC		DC		IR		GC		OS		ALL	
Code	HEX	DEC	HEX	DEC	HEX	DEC	HEX	DEC	HEX	DEC	HEX	DEC
STOP											70	112
USER INTERRUPT											71	113
CAN NOT TEST											72	114
TESTING											73	115

PASS											74	116
SKIPPED											75	117
GFI TRIPPED											79	121
SLAVE FAIL											7A	122
Cs/SHORT FAIL											7B	123
HIGH FAIL	11	17	21	33	31	49	41	65				
SHORT FAIL									61	97		
LOW FAIL	12	18	22	34	32	50	42	66				
OPEN FAIL									62	98		
ARC FAIL	13	19	23	35								
I/O FAIL	14	20	24	36	34	52			64	100		
NO OUTPUT	15	21	25	37	35	53						
VOLTAGE OVER	16	22	26	38	36	54			66	102		
CURRENT OVER	17	23	27	39	37	55			67	103		
INRUSH FAIL			28	40								

Example: The test results of devices:

Master (0x70): 0xAB 0x01 0x70 0x03 0xB1 0x00 0xD7 0x04
Slave (0x01): 0xAB 0x70 0x01 0x12 0xB1 0x01 0x01 0x74 0xD7 0x01
0x63 0x00 0x5A 0x00 0x00 0x00 0x0F 0x00 0x1E 0x00
0x18 0x00 0x7C

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header

0x01 = Destination Address

0x70 = Source Address

0x03 = Data Length

0xB1 = Command Code

0x00 = "00" It queries the last step that begins to execute or has been executed.

(Command Parameter)

0xD7 = "D7" Item Number (Command Parameter)

0x04 = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header

0x70 = Destination Address

0x01 = Source Address

0x12 = Data Length

0xB1 = Command Code

0x01 = New test result (Return Data)

0x01 = Step1 (Return Data)

0x74 = Test result code "PASS" (Return Data)

0xD7 = Item number (Return Data)

0x01 = AC mode (Return Data)

0x63 0x00 = Display Volt 0.099kV (Return Data)

0x5A 0x00 0x00 0x00 = Curr 0.009mA (Return Data)

0x0F 0x00 = ramp time 1.5sec (Return Data)

0x1E 0x00 = test time 3.0sec (Return Data)

0x18 0x00 = fall time 2.4sec (Return Data)
 0x7C = Checksum



When the tester is in pause mode, the data field length of returning may be different from other modes.

Do Get C Standard

Description: It enables the standard capacitance function of OS mode.

Command code: 0x33

Parameter: None

Return data: Reply Message

Example: Master (0x70): 0xAB 0x01 0x70 0x01 0x33 0x5B
 Slave (0x01): 0xAB 0x70 0x01 0x02 0x7F 0x00 0x0E

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
 0x01 = Destination Address
 0x70 = Source Address
 0x01 = Data Length
 0x33 = Command Code
 0x5B = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
 0x70 = Destination Address
 0x01 = Source Address
 0x02 = Data Length
 0x7F = Reply Message Command Code
 0x00 = Reply Message Return Data
 0x0E = Checksum

Reply Message

Description: It queries the performed result of the previous command.

Command code: 0x7F

Parameter: None

Return data: 1 byte
 0 – OK, no error
 1 – Command Error (Include Execution Error)
 2 – Parameter Error

Example: Master (0x70): 0xAB 0x01 0x70 0x01 0x7F 0x0F
 Slave (0x01): 0xAB 0x70 0x01 0x02 0x7F 0x00 0x0E

Example description

The meanings of the 16-bit input settings are as follows:

0xAB = Header
 0x01 = Destination Address
 0x70 = Source Address
 0x01 = Data Length
 0x7F = Command Code
 0x0F = Checksum

The meanings of the returned 16-bit code readings are as follows:

0xAB = Header
0x70 = Destination Address
0x01 = Source Address
0x02 = Data Length
0x7F = Command Code
0x00 = "00" OK, no error (Return Data)
0x0E = Checksum

Serial Number?

Description: It queries the device's serial number.
Command code: 0xFE
Parameter: None
Return data: 1 ~ 31 bytes serial number
Example: Master (0x70): 0xAB 0x01 0x70 0x01 0xFE 0x90
Slave (0x01): 0xAB 0x70 0x01 0x06 0xFE 0x32 0x31 0x33 0x35
0x36 0x8A

Example description

The meanings of the 16-bit input settings are as follows:


0xAB = Header
0x01 = Destination Address
0x70 = Source Address
0x01 = Data Length
0xFE = Command Code
0x90 = Checksum

The meanings of the returned 16-bit code readings are as follows:


0xAB = Header
0x70 = Destination Address
0x01 = Source Address
0x06 = Data Length
0xFE = Reply Message Command Code
0x32 = Byte 1 Return data: 2
0x31 = Byte 2 Return data: 1
0x33 = Byte 3 Return data: 3
0x35 = Byte 4 Return data: 5
0x36 = Byte 5 Return data: 6
0x8A = Checksum

5.7 Flow Diagram


1. Confirm if all of the Slaves' communication is normal or not:



2. Upload the test steps from one slave then download to all slaves.



3. Read the measurement data:



6. RS232 Interface

6.1 Guide

Users can use the computer via the RS232 interface to remote control the tester. This interface applies binary code transmission mode, its command format is the same as the RS485 interface. For the detailed command description, please see *section 5.6 Command Description*.

6.2 Interface Specification

It's a standard RS232 interface and the setting value is as follows:


BAUD RATE : 4800/9600/19200
 PARITY : NONE
 FLOW CTRL. : NONE

6.3 RS-232 Single Unit Connection for Parameter Setting

1. Press **MENU** under the "STANDBY" screen, by using **F1** and **F2** to move the highlight to "OPTION". Next, press **SELECT** to move the highlight to "REMOTE INTERFACE" then press **SELECT** to enter the RS485 setting screen.
2. Use **NEXT** to move the highlight, and **UP**, **DOWN** to change the settings.
3. Setting item descriptions for single unit connecting:
 - a. INTERFACE: Select the RS485 interface
 - b. UNIT TYPE: Select device type as SLAVE.
 - c. BAUD RATE: Select transmission as 4800, 9600, or 19200 baud rate.
 - d. UNIT ADDRESS: Set as 1.


6.4 Connector

RS232 connector of the instrument is a 9-pin D-Sub connector.



Pin Number	Description
1 *	Do not use
2 TxD	Send data
3 RxD	Receive data
4 *	Do not use
5 GND	Ground
6 *	Do not use
7 *	Do not use
8 *	Do not use
9 *	Do not use

6.5 Method of Connecting



6.6 Communication Protocol

This interface applies binary code transmission mode which is the same as RS485, the given command needs to include the destination address and source address. The RS-485 UNIT ADDRESS setting is 1 as connecting a single unit, thus set the destination address to 0x01 and source address to 0x70. About the command format, please refer to *section 5.4 Communication Protocol*.


7. Maintenance

7.1 General

Our warranty (at the front of the manual) attests to the quality of materials and workmanship in our products. If a malfunction should be suspected or other information is desired, application engineers are available for technical assistance. Application assistance is available in Taiwan by calling 886-3-3279999 and asking for application support. For support outside of Taiwan please contact your local Chroma distributor.

7.2 Instrument Return

Before returning an instrument to Chroma for service, please call our Service Department for return material authorization. It will be necessary to include a purchase order number to ensure expedient processing, although units found to be in the warranty period will be repaired at no charge. For any questions on repair costs or shipment instructions please contact our service department. To safeguard an instrument during storage and shipping please use packaging that is adequate to protect it from damage, i.e., equivalent to the original packaging, and mark the box "**Delicate Electronic Instrument**". Return material should be sent freight prepaid.



Chroma
Advancing Excellence



Chroma ATE Inc.

88 Wenmao Rd., Guishan Dist., Taoyuan City 333001, Taiwan

T +886-3-327-9999 | F +886-3-327-8898 | www.chromaate.com | info@chromaate.com