



## Keeping Threaded Fasteners in Their Place

The threaded fastener continues to annoy maintenance crews with its tendency to come undone, but solutions do exist

*Our thanks to Loctite® for allowing us to reprint the following white paper.*

*Original version written by Robert A. Valitsky - Technical Manager, Henkel Corporation*

*Updated by Robert Dunkel, P. Eng - Director of Technical Services, Henkel Corporation*

According to a booklet published by the Industrial Fasteners Institute, called "The Heritage of Mechanical Fasteners," man's invention of nails, rivets, screws and other basic fasteners helped pave the road from the Stone Age to the Space Age. If that is true, then fastener loosening has provided quite a few of the speed bumps and pot holes on that road.

Keeping fasteners tight, particularly the threaded sort, seems like a simple task, but the moving nature of the machinery they are used on is what makes it so troublesome. How nails and rivets work is fairly well known. But because the physics of the threaded fastener is not as well understood, it tends to cause the most problems.

### Causes Of Loosening

Threaded fasteners are employed primarily to clamp objects together using tension. Rotary force or torque imposed on the fastener provides that tension. Problems occur when this clamp load deteriorates.

About 85 percent of the torque and effort of tightening a bolt is absorbed by the friction in the threads and under the head. Only 15 percent of the applied torque produces clamp load. Therefore, high torque may be absorbed by high friction and not produce tension. Torque is not the most precise method of controlling clamp load, although it is the most common. When bolt and nut manufacturing is closely controlled, the tension produced in a bolt for a given torque may vary up and down by 15 percent.

Although it is always the first suspect in any case of lost clamp, vibration, as commonly perceived and observed, is not capable of bolt loosening by itself. If vibration is violent enough to cause shifting of the threads, then it will cause loosening – and in only 50 to 100 cycles. However vibration that violent is usually perceived as shock, shudder or impact. Towards the end of the loosening cycle, common vibration can and will rattle the fastener loose: this is why vibration often takes full blame for loosening.

The actual cause of loosening is side-sliding or shifting of the threads. The empty space between the threads of a nut and bolt leaves room for movement, leading to self-loosening and loss of clamping force. The friction in the threads and under the head of the bolt is reduced to zero when the clamped parts and threads slide sideways to the bolt axis.

Each time side-sliding occurs, the bolt can unwind by itself. The loosening process of a non-locking fastener starts with the first motion. It normally takes less than 100 side motions to completely loosen a bolt. This shifting can occur any time the friction between surfaces, as produced by the clamp load, is exceeded. The three common causes of shifting are bending, differential thermal effects, and applied loads.

### Threadlocking

Various methods and devices have been employed over the years to reduce or prevent loss of clamp load in threaded fasteners.

The earliest attempts involved the use of lock wires and split pins in conjunction with nuts and bolts with holes drilled in them. Although fairly effective, these measures had some serious drawbacks. Each fastener had to be the correct length, and the holes had to be aligned on each individual bolt. Consider the difficulty and time required using this method to assemble numerous parts requiring thousands of threaded fasteners.

As fastener manufacturing skills improved, more complex methods of threadlocking were developed. Two of the most common mechanical methods of threadlocking are the use of washers, and thread distortion. Although these methods can be effective for short-term threadlocking, anaerobic threadlockers can provide short-term, long-term and even permanent tightening when necessary.

### Liquid Threadlockers

The first chemical threadlockers, developed by Loctite® Corporation, eliminated any of the design faults and short comings of threaded fasteners. Chemical threadlockers are anaerobic liquids that cure to a tough,

solid state when activated by a combination of contact with an active metal, and lack of air. The resulting cured material is a thermoset plastic that cannot be liquefied by heating, and resists most solvents.

The purpose of threadlockers is to lock and sometimes seal threaded components without changing fastener characteristics or altering torque-tension relationships. In addition, the chemical fasteners offer a number of other advantages over mechanical tightening methods (i.e. lock washers).

- **Breakloose and Prevailing Torque** – Threadlockers find their way into tiny imperfections of threads. As they cure, these imperfections serve as molds for thousands of tiny keys that resist fastener movement in any dimension
- **Anti-corrosion** – Because threadlockers fill the voids between threads, they block the entry of moisture, preventing corrosion and subsequent part seizure.
- **Strength Control** – Most threadlockers are graded by their various strengths and characteristics into distinct classifications. In North America, the different formulations of Loctite® threadlockers are distinguished by the color of the threadlocking material: low-strength is purple, removable is blue, permanent is red, and the wicking grade formula is green.
- **One size fits all** – Threadlockers do not come in different sizes. The same bottle that locks in a tiny screw also can be used on a large bolt. Stocks of various size mechanical threadlockers are no longer necessary.

### Selecting The Right Threadlocker

There are several key factors to consider when choosing a threadlocking compound: shear strength, cure speed, gap-filling requirements and operating environment.

**Shear Strength:** If all threaded fasteners were designed never to be removed, then only one type of threadlocking compound would be necessary – the strongest available. However, not all threaded fasteners are meant to be permanent. Most assemblies held together with threaded fasteners will, with varying frequency, need to be dismantled for repairs, and maintenance or adjustments. Consequently, threadlockers of various shear strengths are available.

**Cure Speed:** The cure speed of threadlockers can vary, depending on several factors; including but not limited to temperature, base metal, surface treatments, clearance between parts, and surface cleanliness. The use of chemical primers can increase the speed of cure and result in higher ultimate strength.

**Gap Filling Requirements:** Most threaded fasteners are designed with some clearance between their mating surfaces. Larger clearances between mating surfaces require an increased quantity of product to fill the void. Thixotropic liquid threadlockers will easily fill clearances in threaded fasteners, without migrating to other areas of the assembly. Where a higher shear strength product is required, and product migration is considered a potential problem, a higher viscosity compound is recommended.

**Operating Environment:** Both chemical resistance and operating temperature should be considered when selecting a liquid threadlocker.

The chemical resistance properties of threadlocking compounds vary between different grades. The most popular anaerobic products will generally resist water, natural or synthetic lubricating oils, fuels, organic solvents and refrigerants.

Like most organic materials, threadlockers lose strength at elevated temperatures. Most show significant strength retention at temperatures up to 150°C (300°F). High temperature-formulations can increase the working temperature anaerobic products to 230°C (450°F) for those applications where it is considered necessary.

### Removability

The most common myth about liquid threadlockers is that once it is cured, it cannot be removed. In fact, all threadlocked fasteners can be removed. Different grades of threadlocker may be used depending on the task. Fasteners secured with low and medium strength grades can be removed with common hand tools. Those secured with high strength grades can be removed by applying high heat for a specific time. Threadlockers are not just for specialized uses. Threadlockers can perform effectively on fasteners and threaded assemblies of many types and sizes, in most equipment.

### New Form – Solid Threadlockers

One of the newest developments in locking and sealing technologies, to further enhance the quality of maintenance programs in all industries, is the recent introduction of semi-solid threadlockers. The same technology found in liquid thread lockers has now been formulated into a semi-solid stick form. Maintenance crews now have a choice of using a liquid or semi-solid to keep their assembled fasteners from loosening. The threadlocking sticks provide several benefits, which include portability and cleanliness – making them the perfect complement to their liquid counterparts. Threadlocking stick uses include jobs where pre-treating bolts before assembly can be a time saver. Other uses include overhead applications, where a liquid dripping could cause an application issue, or in hard-to-reach areas the sticks may be the preferred material. Liquids are still required for certain applications such as treating fasteners in blind holes. In blind holes, the traditional liquid remains the most effective means to ensure

coverage. The introduction of these new 'solid form' products marks the beginning of a new era for maintenance professionals everywhere. These newly developed products are convenient and simple to use. They can be stored in a pocket or thrown in a toolbox without making a mess. Even hands stay fairly clean during application. These new stick threadlockers are

available in a medium strength formula, which can be removed with hand tools, as well as a high strength formula especially well suited for heavy-duty applications. Other maintenance solutions available in stick form include Pipe Sealant, an anaerobic primer, and Anti-Seize lubricants.

