

3

Matting Edging

High Profile

1.0 Product Description The product is a tapered vinyl strip for application to edges of vinyl matting such as 3M™ Nomad™ Scraper Matting 8100, 8150, 9100 and 3M™ Safety Walk™ Cushion Matting 3400, 3600, 5250, 5270 and 3M™ Safe-tigue Matting.

2.0 Intended Use For use on matting to provide an edge that tapers to the floor.

3.0 Standard Sizes Rolls: 40 ft.

4.0 Colors Black, Granite, Safety Yellow

5.0 Requirements The product shall be a high profile tapered vinyl strip suitable for application to the edges of vinyl or vinyl-backed matting.

Detailed Requirements:

<u>Property</u>	<u>Typical Values</u>
Thickness ASTM D418	Minimum: 0.42 inches (10.6 mm)
Hardness Shore A instantaneous	Minimum: 62 Maximum: 75

6.0 Packaging and Marking Packaging: Rolls – one per case

Marking: Each carton shall be marked with product name, size, color, and manufacturer's trade name.

7.0 Installation

Matting edging can be easily applied to 3M™ Nomad™ Scraper Matting, 3M™ Safety-Walk™ Cushion Matting and 3M™ Safe-tigue™ Matting.

Tools and materials needed:

Utility knife

Straight edge, 3-4 feet long (90-120 cm)

3M™ Matting Edging – Kit or Roll

3M™ Matting Adhesive – one 3 U.S. fl. oz. (88 ml) tube of adhesive will apply approximately 15 ft. (450 cm) of edging.

For best results follow these guidelines:

Before applying edging, ensure that the matting and edging are relaxed and not stretched. Unroll the matting and edging and allow to reach room temperature. Do not stretch matting when applying edging.

1. Be certain sides to be edged are straight. Trim edges with a utility knife (not scissors) and a straight edge if necessary.
2. Cut length of edging to same length as edge of mat.
3. Place edging flat on the floor, grooved side up.
4. Apply two beads of adhesive liberally to the top of edging flap.
5. Place edge of mat on top of edging flap containing adhesive and apply moderate pressure.

Place a weight, such as a board, along the full length of the edging to assure a maximum strength bond. Allow to dry at least eight hours before placing matting into service.

8.0 Weight and Cube per Case

Size	Approximate Weight	Cube
Rolls	13 lb.	0.629 cu. ft.

3M Branch Sales Offices

ANCHORAGE

11151 Calaska Circle
Anchorage, AK 99515
Telephone: 907/522-5200
Facsimile: 907/522-1645

CONTINENTAL UNITED STATES

Customer Service Department
3M Center Building 223-5N-07
St. Paul, MN 55144-1000
Order Entry 1-800-852-9722
Facsimile: 1-800-447-0408

HONOLULU

4443 Malaai Street
Honolulu, HI 96818
Mail to: P.O. Box 30048
Honolulu, HI 96820
Telephone: 808/422-2721
Facsimile: 808/422-9557

3M CANADA

1840 Oxford Street East
London, Ontario, Canada
N5V 3G2
Mail to: P.O. Box 5757
London, Ontario, Canada
N6A 4T1
Telephone: 800/364-3577
Facsimile: 800/479-4453

Important Notice:

This flyer is intended to be an introductory summary. The information provided is based upon typical conditions and is believed to be reliable; however, due to the wide variety of intervening factors 3M does not warrant that the results will necessarily be obtained. All details concerning product specifications and terms of sale are available from 3M.

3

Commercial Care Division

3M Center
St. Paul, MN 55144-1000

3M, Nomad, Safe-tigue, Safety-Walk are
trademarks of 3M.

Copyright © 2000, 3M IPC. All rights reserved.
70-0710-3591-2