




FUNC 2 sec.

Settings

1.1 **UN 12** 0.000 m 0.0000 m 0.000 in 0.00 ft 0'00" 1/32 0 in 1/32

2.1 **BEEP**

3.1 **ELT CAL** ON OFF

+ - Change settings in submenu / turn function ON/OFF

FUNC 2 sec.

Bluetooth / NFC 2 sec.

1.1 **BLUET**

2.1 **NFC**

Transfer value from main line **+ -** Turn function ON/OFF

2 sec.

Memory

1...30 **8.294 m**

Navigate through last 30 values

+ -

Clear memory:

C [Power] + [Memory] 2 sec.

Quick Start

Leica DISTO™ D2/D2G

- 1 Display
- 2 ON/Measure
- 3 Add
- 4 Clear/OFF
- 5 Memory/Timer
- 6 Measuring Reference
- 7 Bluetooth/ NFC
- 8 Functions/ Settings
- 9 Subtract

- when it has to be **right**

Leica
Geosystems

FUNC 2 sec.  5

Timer




Adjust delay of automatic release

+ **-**

FUNC 2x 


Volume



FUNC 2 sec. 


FUNC 4x 

Smart Horizontal



FUNC 6x 

Stake-out




www.disto.com
User Manual:




FUNC 1x 

Area



FUNC 3x 


Triangle Area



FUNC 2 sec. 


FUNC 5x 

Pythagoras (3-point)



FUNC 7x 

Levelling




ON



OFF

2 sec.

