

## 2373-LTC

Adapter, Lemo to Universal TC (TC)

### Highlights

Plug any thermocouple with mini-thermocouple jacks into the universal thermocouple adapter for convenient measurement with the 1523 or 1524 Reference Thermometer. The 2373 LTC lemo-to-universal thermocouple adapter connector supports reference junction compensation (RJC) with its own internal precision thermistor.

