

1672/1673 FC/1674 FC Multifunction Tester









  www.fluke.com

Go to www.fluke.com to register your product and find more information.

To view, print, or download the latest manual or supplement, visit us.fluke.com/user/support/manuals.


To download SmartView® software visit www.fluke.com/smartview-download.

To download the Fluke Connect™ app, go to iTunes or Google play and download Fluke Connect.




OPTIONAL


1




2




3



4






5



6




i



1673 FC/1674 FC

1



2

