

TECHNICAL DATA

FlukeView-2 ScopeMeter® Software for 190 Series III, 190 Series II, MDA-500 Series & 120B Series



Key features

- Store color screen copies on your PC
- Copy screen images into reports
- Capture/store waveform data
- Create/archive waveform references
- Copy waveform data for detailed analysis

Product overview: FlukeView-2 ScopeMeter® Software for 190 Series III, 190 Series II, MDA-500 Series & 120B Series

FlukeView™ ScopeMeter® Software for Windows® helps you get even more diagnostic power out of your Fluke [190 Series III Portable Oscilloscope](#), [Fluke 190 Series II Portable Oscilloscope](#), [Fluke 120B Series Industrial Oscilloscope](#), or [Fluke MDA-500 Series Motor Drive Analyzer](#). With FlukeView ScopeMeter Software, you can quickly and easily store your instrument's screens, copy them into reports or documentation, or capture and store waveform data directly from your ScopeMeter Test Tool to your PC. You can create and archive waveform references for future comparison, copy waveforms from the software into a spreadsheet for detailed analysis, or use cursors within the software to isolate and evaluate specific measurement periods.

- **Documentation**—transfer waveforms, screens and data to your PC for printing or importing data into a report
- **Add text to ScopeMeter Test Tool settings**—give operators guidance when recalling settings
- **Archive**—create a library of waveforms for easy reference, or waveform comparison
- **Analysis**—enable cursors to isolate and analyze specific portions of the waveform and compare specific points in time

- **Instrument control**—Remotely control your ScopeMeter 190 Series III and Series II Portable Oscilloscopes, or your MDA-500 Series Motor Drive Analyzer via a virtual instrument keyboard on your PC

Ordering information



FlukeView™ ScopeMeter® Software for Windows®

FlukeView™ ScopeMeter® Software for Windows®

Includes:

- FlukeView-2 ScopeMeter® Software for 190 Series III, MDA-500 Series & 120B Series

Fluke. *Keeping your world up and running.®*

Fluke Corporation
PO Box 9090, Everett, WA 98206 U.S.A.

For more information call:
In the U.S.A. (800) 443-5853
In Canada (800) 36-FLUKE
From other countries +1 (425) 446-5500
www.fluke.com

©2023 Fluke Corporation.
Specifications subject to change without notice.
07/2023

**Modification of this document is not permitted
without written permission from Fluke Corporation.**