

TECHNICAL DATA

Fluke TRM50 Coaxial Feed-through BNC Male to BNC Female Cable Terminator



Product overview: Fluke TRM50 Coaxial Feed-through BNC Male to BNC Female Cable Terminator

TRM50 Coaxial Feed-through BNC male to BNC female Cable Terminator.

Specifications: Fluke TRM50 Coaxial Feed-through BNC Male to BNC Female Cable Terminator

Specifications	
Impedance	50 Ohm
Max Voltage over ground	1000 V CAT III
Max power	1 W



Ordering information



Fluke TRM50



Fluke. Keeping your world up and running.®

Fluke Corporation

PO Box 9090, Everett, WA 98206 U.S.A.

For more information call: In the U.S.A. (800) 443-5853 In Canada (800) 36-FLUKE From other countries +1 (425) 446-5500 www.fluke.com ©2022 Fluke Corporation.

Specifications subject to change without notice.
11/2022

Modification of this document is not permitted without written permission from Fluke Corporation.