






























# T15 SERIES TIPS

FOR FM-203, FM-204, FM-205, FX-951 and FM-206 STATIONS




UNIT: mm (inch)

N T17 tips and nozzles can be used with the Nitrogen Soldering System (see page 21).

\*T15-D16 available in pure nickel construction as T15-1608 for soldering with specialized alloys

# T15 SERIES TIPS

FOR FM-203, FM-204, FM-205, FX-951 and FM-206 STATIONS













UNIT: mm (inch)

**N** T17 tips and nozzles can be used with the Nitrogen Soldering System (see page 21).



# T15 SERIES TIPS











FOR FM-203, FM-204, FM-205, FX-951 and FM-206 STATIONS



UNIT: mm (inch)

# T15 SERIES TIPS

FOR FM-203, FM-204, FM-205, FX-951 and FM-206 STATIONS












UNIT: mm (inch)



# T15 SERIES TIPS

FOR FM-203, FM-204, FM-205, FX-951 and FM-206 STATIONS



UNIT: mm (inch)

### **N** Cross Reference Guide for T17 Tips and N2 Nozzles

T17 TIP		N2 NOZZLE	
Tip Shape	Part Number	Part No.	Part Name
2BC, 2BCF	T17-BC2, T17-BCF2	B2706	Nozzle assembly A
0.2J	T17-J02	B2707	Nozzle assembly B
1.6D, 0.5B, 2.4D	T17-D16, T17-B2, T17-D24	B2708	Nozzle assembly C
0.8D	T17-D08	B2709	Nozzle assembly D
1BC, 1BCF	T17-BC1, T17-BCF1	B2899	Nozzle assembly F
3BC, 3BCF	T17-BC3, T17-BCF3	B2900	Nozzle assembly G
KU	T17-KU	B2901	Nozzle assembly H
KF	T17-KF	B2923	Nozzle assembly J
KR	T17-KR	B2902	Nozzle assembly I

UNIT: mm (inch)