


9772-90 Replacing the Pin

The model 9772-90 pin is a replacement part for the model 9772 PIN TYPE LEAD. Perform the following steps to replace the pin.



Model 9772-90's pin


1. Turn off the power of the device and remove the 9772.
2. Pull out the pin tip to be replaced, using pliers or a similar tool.

Model 9772
PIN TYPE LEAD



3. Replace the 9772-90 pin tip by inserting a new pin into the socket and pressing against a hard board or other surface to fix the pin firmly in place.

Model 9772-90's pin



4. Check the performance. Measure an object with a known resistance. Make sure that the measured resistance is correct before using the pin type lead.

Specifications

Operating temperature and humidity	0°C to 40°C (32°F to 104°F), 80%RH or less (no condensation)
Storage temperature and humidity	-10°C to 50°C (14°C to 122°C), 80%RH or less (no condensation)
Operating Environment	Altitude up to 2000 m (6562 feet), Indoors
Size&Weight	Approx. 19 mm (0.75")/ Approx. 0.15 g (0.005 oz.)
Accessories	Instruction manual