# DPM 702S

# 31/2 Digit Dual Channel LCD Module

No .695 - Page 1 of 2

An ultra-low profile LCD meter using advanced components and construction techniques to provide an unrivaled combination of dual channel voltage measurements and low cost. This product is ideal for those applications where "matched" readings are required, e.g.: voltage and current, temperature and humidity, etc. Both measurement inputs share a common ground line, thereby reducing the number of connections to a minimum. The very low current consumption results in a long battery life and makes it especially suitable for portable equipment. A low battery warning circuit is fitted as standard. The 10-way pin header can be replaced by screw terminal blocks on request. Contact your nearest Lascar Sales Office for further details.

6.4mm (0.25") Digit Height

- Dual Channel
- **@** 200mV d.c. Full Scale Reading (F.S.R.)
- **U** Selectable Decimal Points
- Auto-zero, Auto-polarity
- Common Signal Ground
- Annunciators

### **SCALING**

The full scale reading (F.S.R.) of each measurement channel may be altered by the addition of two resistors

Ra and Rb per channel- see table. Each measurement channel will require recalibration by adjusting *CAL A* and *CAL B*.



Ra	Rb
910k	100k
1M	10k
1M	1k
1M	100R
0R	1k
0R	100R
0R	10R
0R	1R
	910k 1M 1M 0R 0R 0R 0R

Dual Channel Meter			Stock Number DPM 702S			
Specification (channel A or B)	Min.	Тур.	Max.	Unit		
Accuracy (overall error)*		0.05	0.1	% (±1 count)		
Linearity			±1	count		
Full scale reading	-199.9		199.9	mV d.c.		
Resolution		100		μV d.c.		
Sample rate		3		samples/sec		
Operating temperature range	0		50	°C		
Temperature stability		100		ppm/°C		
Supply voltage	3.5	5	7	V d.c.		
Supply current		700		μΑ		
Input leakage current (Vin= 0V)		1	10	рА		

\* To ensure maximum accuracy, re-calibrate periodically.



# Fit the bezel to the front of the panel, then locate the meter to the bezel from behind the panel. Using the screws provided, secure the two plastic spring clips to the rear of the meter. The meter is designed to fit directly onto OKW Type M, P and Veronex size 3 enclosures.



LASCAR ELECTRONICS LTD. MODULE HOUSE, WHITEPARISH, WILTSHIRE SP5 2SJ UK TEL: +44 (0)1794 884567 FAX: +44 (0)1794 884616 E-MAIL: sales@lascarc.o.uk LASCAR ELECTRONICS INC. 4258 WEST 12th Street, ERIE, PA 16505 USA TEL: +1 (814) 835 0621 FAX: +1 (814) 838 8141 E-MAIL: us-sales@lascarelectronics.com LASCAR ELECTRONICS (HK) LTD. 8th FLOOR, CHINA AEROSPACE CENTRE, 143 HOI BUN ROAD, KWUN TONG, KOWLOON, HONG KONG TEL: +852 2389 6502 FAX: +852 2389 6535 E-mail: saleshk@lascar.com.hk

## **PIN FUNCTIONS**

- Positive power supply connection. 1. V+ GND 2. 0Vsupply connection. 3. INHIA Positive measuring differential input. Analogue inputs must be no closer than 1V to the positive supply. 4. IN HIB Positive measuring differential input. 5. IN LO Negative measuring differential input. 6. POL-B Drive pin for channel B polarity sign. Connect to V+ to invert polarity sign when measuring Voltage and Current simultaneously. 7. TEST-A Connect to V+ to display all Channel A segments, except annunciators. 8. TEST-B Connect to V+ to display all Channel B segments, except annunciators. 9. Not connected. N/C
- 10. N/C Not connected.

### SAFETY

To comply with the Low Voltage Directive (LVD 93/68/EEC), input voltages to the module's pins must not exceed 60Vdc. If voltages to the measuring inputs do exceed 60Vdc, then fit scaling resistors externally to the module. The user must ensure that the incorporation of the DPM into the user's equipment conforms to the relevant sections of BS EN 61010 (Safety Requirements for Electrical Equipment for Measuring, Control and Laboratory Use).





Specifications liable to change without prior warning