


















BNC Adapters

- Adapters provide a simple connection between 2 of the same series of jack or between different series of connectors without replacing one or the other
- Right angle adapters can be used to eliminate sharp cable bends deteriorating electrical signal
- Weatherproof for indoor/outdoor use
- Terminators prevent unwanted interference and signals from entering the cable to reduce frequency loss

 <p>100-350TP Between Series Adapter RCA Phono Male / BNC Female, 50 Ohm</p>	 <p>301-0401TP Between Series Adapter BNC Male / F Female, 50 Ohm</p>	 <p>301-125TP Between Series Adapter BNC Male /RCA Phono Female, 50 Ohm</p>	 <p>301-301-75TP BNC Adapter Straight, Male / Male, 75 Ohm</p>	 <p>301-301TP BNC Adapter Straight, Male / Male, 50 Ohm</p>
 <p>301-RA-350TP BNC Adapter Right Angle, Male / Female, 50 Ohm</p>	 <p>301-RA75-350TP BNC Adapter Right Angle, Male / Female, 75 Ohm</p>	 <p>301-T75TP BNC Male Termination, 75 Ohm, ½ Watt 1% White Cap</p>	 <p>327-1175TP BNC Adapter Straight, Female / Female, 75 Ohm</p>	 <p>327-11TP BNC Adapter Straight, Female / Female, 50 Ohm</p>
 <p>301-32750TP BNC Adapter “T”, Female / Male / Female, 50 Ohm</p>	 <p>301-327750TP BNC Adapter Goal Post, Female / Male / Female, 50 Ohm</p>	 <p>301-327T75TP BNC Adapter “T”, Fe- male / Male / Female, 75 Ohm</p>	 <p>301-T3TP BNC Adapter “T”, All Male, 50 Ohm</p>	 <p>327-3TP BNC Adapter “T”, All Female, 50 Ohm</p>
 <p>327-753TP BNC Adapter “T”, All Female, 75 Ohm</p>	 <p>329-0TP BNC Adapter Bulk- head, Female / Female, 50 Ohm</p>	<p>See Next Page for Ordering Information</p>		

BNC Adapters

Ordering Information

Part Number	Description
100-350TP	Between Series Adapter -- RCA Phono Male / BNC Female. 10 PK
301-0401TP	Between Series Adapter -- BNC Male / F Female. 10 PK
301-125TP	Between Series Adapter -- BNC Male / RCA Phono Female. 10 PK
301-301-75TP	BNC Adapter Straight -- Male/Male, 75 Ohm. 10 PK
301-301TP	BNC Adapter Straight -- Male/Male, 50 Ohm. 10 PK
301-32750TP	BNC Adapter "T" -- Female/Male/Female, 50 Ohm. 10 PK
301-327750TP	BNC Adapter Goal Post -- Female/Male/Female, 50 Ohm. 10 PK
301-327T75TP	BNC Adapter "T" -- Female/Male/Female, 75 Ohm High Performance. 10 PK
301-RA-350TP	BNC Adapter Right Angle -- Male/Female, 50 Ohm. 10 PK
301-RA75-350TP	BNC Adapter Right Angle -- Male/Female, 75 Ohm. 10 PK
301-T3TP	BNC "T" Adapter -- All Male. 10 PK
301-T75TP	BNC Male Termination -- 75 Ohm, 1/2 Watt 1%, Purple Cap. 10 PK
327-1175TP	BNC Adapter Straight -- Female/Female -- 75 Ohm High Performance. 10 PK
327-11TP	BNC Adapter Straight -- Female/Female -- 50 Ohm. 10 PK
327-3TP	BNC Adapter "T" -- Female/Female/Female -- 50 Ohm. 10 PK
327-753TP	BNC Adapter "T" -- Female/Female/Female -- 75 Ohm High Performance. 10 PK
329-0TP	BNC Adapter Bulkhead -- Female/Female -- 50 Ohm. 10 PK