


User Manual



# LT65

## Digital Light Meter



## ***Introduction***

---

Congratulations on your purchase of the Tripplett LT65 Digital Light Meter. The LT65 Digital Light meter is designed for Light intensity measurement projects, quality control, health control and measuring Light intensity of various kind of environments, like factories, parking lots, schools, offices, transportation lines, schools and many other environments.

## ***Safety***

---

- Do not operate the meter in environments where the following are present: explosive gases (or materials), combustible gases (or materials), steam, or dust.
- Please replace the battery immediately when the low battery symbol appears on the LCD.
- Do not touch the meter's circuit board for any reason; static electricity or contamination could damage the sensitive components.
- This instrument was designed for pollution degree 2. Operation Altitude: Up to 2000m (7000').

## ***Description***


---

1. LCD Display
2. Function Buttons
3. Light Sensor





## Display Overview

---




- **MAX** : Maximum display symbol.
- **MIN** : Minimum display symbol.

-  : Low battery symbol, which shows the power is low battery. Please change a new battery.
-  : Data hold symbol
- TIME : Time display, format: hour : minute


## • ***Function Buttons***

---



-  : Long press the button "TIME" for 2 seconds to enter the time setting page. Short press the button "TIME" to select the value of "hour" and "minutes" to be set. Press the button "HOLD" to change the value. Long press the button to exit the time setting.



-  : Maximum, Minimum function option, pressing this button for 3 seconds exits this function., REC、Lux/Fc、LEVEL' also will also exit this function.



-  : Displys HOLD , LCD will show HOLD symbol.




- : Range selection function. Range selection function will disable under the "REC" function. Choose measurement range before enter "REC" function.



- : Backlight Function



- : Changes UNITS Fc/Lux
- 1Fc=10.76Lux, 1KLux=1000Lux, 1KFc=1000Fc



- : Power ON / OFF Button
- To Power ON – Press and Hold this button for more than 1 second until LCD screen full of display.
- To Power OFF – Press and Hold this button for more than 3 seconds until LCD screen have no any display.

## ***Operation***

---

1. POWER ON: Press the POWER button for more than 1 second until LCD displays..
2. POWER OFF: Press the POWER button for more than 3 seconds until LCD extinguishes.
3. Choose Lux or FC unit : Transfer measurement range switch can exchange

Lux or FC unit.

4. Transfer light probe cover and make it vertical to aligned light source.
5. Read the measurement data from LCD screen.
6. Over range: If the instrument only display“OL”, means the signal input is too strong, should choose a higher range. Measurement range will display below the LCD screen.  
LUX :400 -> 4K -> 40k -> 400k; FC: 40 -> 400-> 4k -> 40k.
7. Data holding function: Press HOLD button and choose data holding function.
8. Maximum and minimum function: Press MAX/MIN button choose the maximum reading and minimum reading function. Press MAX/ MIN or ( LEVEL、 LUX/FC、 REC) for 3 seconds exit this function.
9. USB function: connect with the computer's USB interface.
10. Backlight function: Press Backlight button to start up the function, press it again to exit the function.
11. When all measurement are done, please restore the light probe cover and turn off the instrument.

## ***Battery Replacement***

---

When  appears on the LCD, the 3\*1.5V AA battery must be replaced.

1. Disconnect the sensor.
2. Remove the meter's rubber protective jacket
3. Use a Phillips screwdriver to open the rear battery compartment
4. Replace the 3\*1.5V AA battery
5. Close the battery compartment and replace the meter's protective jacket

## **Warranty Information**

Triplett / Jewell Instruments extends the following warranty to the original purchaser of these goods for use. Triplett warrants to the original purchaser for use that the products sold by it will be free from defects in workmanship and material for a period of (1) one year from the date of purchase. This warranty does not apply to any of our products which have been repaired or altered by unauthorized persons in any way or purchased from unauthorized distributors so as, in our sole judgment, to injure their stability or reliability, or which have been subject to misuse, abuse, misapplication, negligence, accident or which have had the serial numbers altered, defaced, or removed. Accessories, including batteries are not covered by this warranty

**Copyright © 2020 Triplett**

## ***Specifications***

---

Display	4 Digit LCD Display
Measurement Range	0 to 400,000 Lux; 0 to 40,000 Fc 1 Fc = 10.76 Lux; 1kLux = 1000 Lux; 1k Fc = 1000 Fc
Notices	
Overload Display	LCD displays "OL"
Spectral Response	CIE Appropriate Light (CIE eye response curve)
Spectral Precision	CIE V <sub>λ</sub> function f1'% less than or equal to 6%
Cosine Response Precision	f2' less than or equal to 2% ±3% reading ±0.5%FS (<10,000 Lux) ±4% reading ±10d (>10,000 Lux)
Light probe	Silicon light diode and a spectral response filter
Power	(3) 1.5V batteries
Light Probe Length	59" (150cm)
Light Probe Volume	4.5" x 2.4" x 0.8"( 115 x 60 x 20mm)
Dimensions	6.4" x 2.4 x 1.2"(162 x 62 x 30mm)
Weight	9.2 oz (260g)
Accessories	Canvas bag, User Manual, Batteries,