# Glove CAFE Installation, Operation and Maintenance





Made in the United States of America



Figure 1. Desco 19298 Glove CAFE

### **Description**

The Desco 19298 Glove CAFE (Constant Area and Force Electrode) meets ANSI/ESD SP15.1 requirements for measuring the intrinsic electrical resistance of gloves and finger cots. It also measures their electrical resistance together with personnel as a system.

The Desco Glove CAFE is compatible with the following Desco Surface Resistance Meters:

Item	Description
<u>19290</u>	Digital Surface Resistance Meter Kit
<u>19291</u>	Digital Surface Resistance Meter
<u>19784</u>	Analog Surface Resistance Meter Kit
<u>19786</u>	Analog Surface Resistance Meter
<u>19640</u>	Surface Resistance Checker

## **Packaging**

- 1 Glove CAFE
- 1 Wrist Cord without Resistor

# **Operation**

- 1. Fit a wristband snugly onto the wrist.
- Snap the wrist cord to the wristband. Use the included non-resistor wrist cord if performing a Low Voltage System Resistance Test per sections 6.6 and 6.7 of ANSI/ESD SP15.1. Use a one megohm wrist cord if performing a High Voltage System, High Resistance Test per section 6.8 of ANSI/ESD SP15.1.

- Plug the wrist cord into one input of the resistance meter.
- Attach the Glove CAFE to the other input of the resistance meter.
- Wear the glove on the same hand as the wristband and wait a minimum of 15 seconds before beginning the electrical measurement.
- 6. Balance the Glove CAFE on the fingerprint side of the thumb or first finger of choice on the hand wearing the glove.
- Take a resistance measurement using the resistance meter.



Figure 2. Using the Glove CAFE Test Electrode with the Desco 19290 Digital Surface Resistance Meter

DESCO WEST - 3651 Walnut Avenue, Chino, CA 91710 • (909) 627-8178

DESCO EAST - One Colgate Way, Canton, MA 02021-1407 • (781) 821-8370 • Website: Desco.com

# **Specifications**

#### **Glove CAFE**

Dimensions 1.0" x 3.0" x 4.3"

(25 mm x 76 mm x 109 mm)

Weight 1.0 lbs (454 g)

Country of Origin United States of America

#### **Wrist Cord**

Retracted Length 6.0' (1.8 m) Extended Length 8.5' (2.6 m)

Termination 1 Black thermoplastic elastomer

molded banana plug

Termination 2 Red thermoplastic elastomer

molded 4 mm medical snap socket

Wire Insulation Black PVC

Resistor None

Country of Origin United States of America

# Limited Warranty, Warranty Exclusions, Limit of Liability and RMA Request Instructions

See the Desco Warranty -

Desco.com/Limited-Warranty.aspx

DESCO WEST - 3651 Walnut Avenue, Chino, CA 91710 • (909) 627-8178

DESCO EAST - One Colgate Way, Canton, MA 02021-1407 • (781) 821-8370 • Website: Desco.com

TB-3085 Page 2 of 2 © 2020 DESCO INDUSTRIES INC