

**RM2000B  
TDS1000B, TDS1000C-EDU, TDS2000B, and TDS2000C Series  
Rackmount Kit**

**Instructions**

**Warning**

The servicing instructions are for use by qualified personnel only. To avoid personal injury, do not perform any servicing unless you are qualified to do so. Refer to all safety summaries prior to performing service.

[www.tektronix.com](http://www.tektronix.com)



071-1984-01

**Tektronix**

Copyright © Tektronix. All rights reserved. Licensed software products are owned by Tektronix or its subsidiaries or suppliers, and are protected by national copyright laws and international treaty provisions.

Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specifications and price change privileges reserved.

TEKTRONIX and TEK are registered trademarks of Tektronix, Inc.

## Contacting Tektronix

Tektronix, Inc.  
14150 SW Karl Braun Drive  
P.O. Box 500  
Beaverton, OR 97077  
USA

For product information, sales, service, and technical support:

- In North America, call 1-800-833-9200.
- Worldwide, visit [www.tektronix.com](http://www.tektronix.com) to find contacts in your area.

# Service Safety Summary

Only qualified personnel should perform service procedures. Read this *Service Safety Summary* and the *General Safety Summary* before performing any service procedures.

**Do Not Service Alone.** Do not perform internal service or adjustments of this product unless another person capable of rendering first aid and resuscitation is present.

**Disconnect Power.** To avoid electric shock, switch off the instrument power, then disconnect the power cord from the mains power.

**Use Care When Servicing With Power On.** Dangerous voltages or currents may exist in this product. Disconnect power, remove battery (if applicable), and disconnect test leads before removing protective panels, soldering, or replacing components.

To avoid electric shock, do not touch exposed connections.

## Service Safety Summary

# Kit Description

The RM2000B rackmount is designed for use with TDS1000B, TDS1000C-EDU, TDS2000B, and TDS2000C series oscilloscopes.

## Products

TDS1000B and TDS1000C-EDU Series	All serial numbers
TDS2000B and TDS2000C Series	All serial numbers

## Kit Parts List

**NOTE.** This kit is suitable only for TDS1000B, TDS1000C-EDU, TDS2000B, and TDS2000C oscilloscopes. Do NOT use this kit for TDS1000 or TDS2000 models.






Table 1: Kit parts list

Circuit/ figure Number	Quantity	Part number	Description
1-1	1 each	RM2000B	RM2000B Rackmount kit, includes a front and back panel set, 2 handles, instructions, bag of screws
-2	1 each	071-1984-xx	RM2000B Rackmount kit instructions, English (this document)
-3	1 each	016-1978-xx	Standard mounting hardware in plastic bag includes:
	4 each	—	(for handles) screw 8-32 x 1/2 phil pan
	4 each	—	(for handles) #8 med spit L/W
	4 each	—	screw 10-32 x 3/4 poz

**Table 1: Kit parts list, (cont.)**

Circuit/ figure Number	Quantity	Part number	Description
	4 each	–	screw 12-24 x 3/4 poz
	4 each	–	screw M5 x 16 oval head phil
	4 each	–	screw M6 x 16 oval head phil
	4 each	–	flat washer (M5 and #10 screws)
	4 each	–	flat washer (M6 and #12 screws)
	4 each	–	#10 finish washer

To install a TDS1000B, TDS1000C-EDU, TDS2000B or TDS2000C series instrument, refer to the following illustration.

**Figure 1: RM2000B Rackmount assembly**

\* With a TEK-USB-488 adapter connected, the dimension is 160.3 mm (6.311 in).

**Figure 2: Dimensions of the RM2000B Rackmount**