# **GROUND RESISTANCE TESTERS** MULTI-FUNCTION

### **MODEL 6471**

*Test ground resistance without the need of auxiliary rods or with the 3- and 4- Point methods* 

### **SPECIFICATIONS**

SPECIFICATIONS								
MODEL	6471							
ELECTRICAL								
2 Clamp Measurement								
Range	0.10 to 500Ω							
Resolution	0.01 to 1Ω							
Measurement Frequency	Auto: 1611Hz Manual: 128Hz-1367Hz-1611Hz-1758Hz							
<b>3-Point Measurement</b>								
Range (Auto-Ranging)	$0.09\Omega$ to $99.9k\Omega$							
Resolution	0.01Ω to 100Ω							
Test Voltage	Nominal 16 or 32Vrms user selectable							
Resistance Measurement Frequency	41 to 513Hz automatic or user selectable							
Test Current	Up to 250mA							
Accuracy	±2% of Reading + 1ct @ 128Hz							
Soil Resistivity 4-Point Meas	urement							
Test Method	Wenner or Schlumberger selectable with automatic calculation in Ω-meters							
Range (Auto-Ranging)	0.01 to 99.99k $\Omega$ ; $\rho$ max: 999k $\Omega$ m							
Resolution	0.001 to 10Ω							
Test Voltage	16 or 32V user selectable							
Frequency	From 41 to 128Hz selectable							
External Voltage Measureme	ent							
Range (Auto-Ranging)	0.1 to 65.0Vac/dc – DC to 440Hz							
Accuracy	±2% of Reading + 1ct							
<b>Resistance Measurement (B</b>	ond Testing)							
Measurement Type	2-Pole (with lead resistance compensation) or 4-Pole (Kelvin sensing) user selectable							
Range (Auto-Ranging)	2-Pole 0.12 to 99.99kΩ; 4-Pole 0.02 to 99.99kΩ							
Accuracy	$\pm 2\%$ of Reading + 2cts							
Test Voltage	16Vbc (+, - or auto polarity)							
Test Current	Up to 250mA max							
Data Storage								
Memory Capacity	512 test results (64KB)							
Communication	Optically Isolated USB							
Power Source	9.6V rechargeable battery pack (included)							
Recharging Source	110/220V, 50/60Hz external charger with 18Vdc, 1.9A output							

### ACCESSORIES





MN82 CURRENT PROBE (2mA to 10Arms) Catalog #2135.71 SR182 CURRENT PROBE (0.5MA TO 40ARMS) Catalog #2135.72

2 probes required to perform stakeless testing.

Technical Assistance (800) 343-1391

Catalog #2135.85 Set of (2),

for use with ground kit spools

**REEL CADDY** 





#### **GROUND RESISTANCE MEASUREMENT USING 2 CLAMPS**

For systems with parallel ground connections, Models 6471 and 6472 are capable of accurately measuring a ground resistance using clamps only. This method involves placing 2 clamps around the ground conductor to be tested and connecting them each to the instrument. One clamp injects a known signal (32V/1367Hz) while the other clamp measures the current circulating in the loop. This method saves considerable time when ground testing because it is no longer necessary to set up auxiliary rods or to disconnect the ground connector.

## **PRODUCT INCLUDES**

#### CAT #2135.48

Meter, carrying bag , 110/240V power adapter with US power cord, optical USB cable, rechargeable NiMH battery, DataView® software, ground tester workbook and a user manual.

#### CAT #2135.49

Meter, carrying bag , set of (2) SR182 current probes, 110/240V power adapter with US power cord, optical USB cable, rechargeable NiMH battery, DataView® software, Ground Tester workbook and a user manual.

#### KIT SHOWN 300 FT KIT: CATALOG #2135.50

Includes meter, carrying bag for meter, carrying bag for kit, (2) 300 ft color-coded leads on spools (red/blue), (2) 5 ft color-coded leads (red/ blue), (2) 100 ft color-coded leads (hand-tied, green/black), (2) SR182 current probes, rechargeable NiMH batteries, optical USB cable, power adapter 110/240V with power cord 115V US, (4) T-shaped auxiliary ground electrodes, set of (5) spaded lugs, (1) 100 ft tape measure, USB thumb drive supplied with DataView<sup>®</sup> software, Ground Tester workbook and a user manual.



Rev.00 05/2021



# **GROUND RESISTANCE TESTERS** MULTI-FUNCTION

### **MODEL 6472**

Used under difficult conditions such as the presence of high stray currents that normally affect accuracy

### **SPECIFICATIONS**

SPECIFICATIONS								
MODEL	6472							
ELECTRICAL								
2 Clamp Measurement								
Range	0.1 to 500Ω							
Resolution	0.01 to 1Ω							
Measurement Frequency	Auto: 1611Hz Manual: 128Hz-1367Hz-1611Hz-1758Hz							
<b>3-Point Measurement</b>								
Range (Auto-Ranging)	0.09Ω to 99.9kΩ							
Resolution	0.01Ω to 100Ω							
Test Voltage	Nominal 10, 16, 32 or 60Vrms user selectable							
Resistance Measurement Frequency	41 to 5078Hz automatic or user selectable							
Test Current	Up to 250mA							
Accuracy	±2% of Reading + 1ct @ 128Hz							
Soil Resistivity 4-Point Meas								
Test Method	Wenner or Schlumberger selectable with automatic calculation of test results in $\Omega\text{-meters}$							
Range (Auto-Ranging)	0.01 to 99.99k $\Omega$ ; $\rho$ max: 999k $\Omega$ m							
Resolution	0.01 to 100Ω							
Test Voltage	16 or 32V user selectable							
Frequency	From 41 to 128Hz selectable							
External Voltage Measureme	ent							
Range (Auto-Ranging)	0.1 to 65.0Vac/dc – DC to 440Hz							
Accuracy	$\pm 2\%$ of Reading + 1ct							
<b>Resistance Measurement (B</b>	÷.							
Measurement Type	2-Pole (with lead resistance compensation) or 4-Pole (Kelvin sensing) user selectable							
Range (Auto-Ranging)	2-Pole 0.12Ω to 99.99kΩ; 4-Pole 0.02Ω to 99.99kΩ							
Accuracy	±2% of Reading + 2cts							
Test Voltage	16Vbc (+, - or auto polarity)							
Test Current	Up to 250mA max							
Data Storage								
Memory Capacity	512 test results (64KB)							
Communication	Optically Isolated USB							
Power Source	9.6V rechargeable battery pack (included)							
Recharging Source	110/220V, 50/60Hz external charger with 18Vdc, 1.9A output							



DataView<sup>®</sup>



The Model 6472 provides an automated way to measure the value of the earth/ground using the Fall-of-Potential method and storing measurements.

## **PRODUCT INCLUDES**

cover closed

Meter, carrying bag, 110/240V power adapter with US power cord, optical USB cable, rechargeable NiMH battery pack, DataView® software, ground tester workbook and a user manual.

# **TEST KITS**

6472 METER 300 ft Kit: Catalog #2135.53 500 ft Kit: Catalog #2135.54 (shown)

Refer to page 79 for Model 6472 Kit descriptions Catalog #2135.35, #2135.36 and #2135.37



## ACCESSORIES

MN82 CURRENT PROBE (2mA to 10Arms) Catalog #2135.71



SR182 CURRENT PROBE (0.5MA TO 40ARMS) Catalog #2135.72



**REEL CADDY** Catalog #2135.85 Set of (2), for use with ground kit spools



Rev.00 05/2021

# **GROUND RESISTANCE TESTERS** MULTI-FUNCTION

# LARGE FUNCTIONAL DISPLAYS

## **FEATURES**

- Ground Integrity® Measurement
- Ground Resistance testing using the 2 clamp method (no auxiliary rods needed)
- 2- and 4-Point Bond Resistance/Continuity measurement (DC Resistance) with automatic polarity reversal
- 3-Point Fall-of-Potential measurement with manual or automatic frequency selection
- 4-Point Soil Resistivity measurement with automatic calculation of Rho (r) and user selection of the Wenner or Schlumberger test method
- 3-Point Earth Coupling measurement
- Manual and Automatic frequency scan from 41 to 5078 Hz for optimum test accuracy in electrically noisy environments
- Selectable test voltage of 16 or 32V up to 250mA of test current
- · Auto Power OFF feature
- Automatic recognition of all electrode connections and their resistance value
- Stores up to 512 complete test results in internal memory
- Display with automatic backlight when entering a function
- Optically isolated USB communication cable included
- Rechargeable NiMH batteries from wall charger or vehicle power
- Rugged dustproof and water-resistant field case (IP53 rated in closed position)
- Grounding standards IEC 61557 parts 4 and 5 compliant
- Includes DataView<sup>®</sup> software for set up, data retrieval, real-time display, analysis, report generation and system configuration
- · Can also be used for continuity tests on bonding

#### 4-POINT BOND TEST



The 4-Point Bond test shows lead connections, bond resistance test results, test voltage and current.

#### SCHLUMBERGER TEST

#### (+) $\rho_s$ (+) $\rho_s$

The Schlumberger test displays test lead connection, soil resistivity ( $\rho$ ) test results and electrode spacing.

#### DATA STORAGE



Memory Recall displays test results stored at a specific memory location.

### ACCESSORIES

MN82 AC CURRENT PROBE Catalog #2135.71

#### **3-POINT FALL-OF-POTENTIAL TEST**



The 3-Point Fall-of-Potential test displays test lead connection, grounding rod resistance and test electrode resistances.

#### **TWO CLAMP TEST**



The 2 Clamp method displays clamp connection resistance, test current and frequency.

#### WENNER TEST



The Wenner test displays test lead connection, soil resistivity  $(\rho)$  test results, electrode spacing and resistance.

#### SR182 AC CURRENT PROBE REEL CADDY (0.5MA TO 40ARMS) Catalog #2135.85

Set of (2), for use with ground kit spools

2 probes required to perform stakeless testing.

Catalog #2135.72

CATALOG NO.	DESCRIPTION
2135.48	Ground Resistance Tester Model 6471 (Digital, 3-Point, 4-Point, Clamp-on (SR182 probes not included), DataView® Software)
2135.49	Ground Resistance Tester Model 6471 (Digital, 3-Point, 4-Point, Clamp-on, (includes 2-SR182 probles), DataView® Software)
2135.50	Ground Resistance Tester Model 6471 Kit – 300 ft (Catalog #2135.49 and Catalog #2135.36)
2135.51	Ground Resistance Tester Model 6472 (Digital, 2-Point, 3-Point, 4-Point, Bond Test, DataView® software)
2135.53	Ground Resistance Tester Model 6472 Kit – 300 ft (Catalog #2135.51 and Catalog #2135.36)
2135.54	Ground Resistance Tester Model 6472 Kit – 500 ft (Catlog #2135.51 and Catalog #2135.37)
2135.60	Ground Resistance Tester Model 6471 Kit – 300 ft w/o Probes (Catalog #2135.48 and Catalog #2135.36)
2135.61	Ground Resistance Tester Model 6471 Kit – 500 ft w/o Probes (Catalog #2135.48 and Catalog #2135.37)




### **GROUND TESTERS MODELS 6471 & 6472 — TYPICAL DATAVIEW® FUNCTIONAL DISPLAYS**


#### **2 CLAMP METHOD SETUP**

👌 Ground Tester Control Panel		-		×
File View Instrument Tools Wi	ndow Help			
1 2 Ω ↓ 1 4 2 2 3 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2		START	ST	DP
Configuration				-
Load From File	AutoFrequency v			
Save To File				
Set Instrument Clock Buzzer	2 Clamps			
Disabled 🛞 Enabled 🔾	100	•		
	Input Noise 1 Input ES = GA			

#### SELECTIVE 3-POINT TESTING OF MULTIPLE RODS



#### BONDING



### **OPTIONAL KITS**

#### 150 FT KIT

Catalog #2135.35 Test Kit for 3-Point testing includes carrying bag, (2) 150 ft color-coded leads on spools (red/blue),



(1) 30 ft lead (green), (2) 14.5" T-shaped auxiliary ground electrodes, a set of (5) spaded lugs and 100 ft tape measure.



#### **300 FT KIT** Catalog 2135.36

Test Kit for 4-Point testing includes carrying bag, (2) 300 ft color-coded leads on spools

(red/blue), (2) 5 ft color-coded leads (red/blue), (2) 100 ft color-coded leads (green and black), (4) 14.5" T-shaped auxiliary ground electrodes, a set of (5) spaded lugs and 100 ft tape measure.




### **500 FT KIT**

Catalog #2135.37 Test Kit for 4-Point testing includes carrying bag, (2) 500 ft color-coded leads on spools (red/ blue), (2) 5 ft color-coded



leads (red/blue), (2) 100 ft color-coded leads (green and black), (1) 30 ft lead (green), (4) 14.5" T-shaped auxiliary ground electrodes, a set of (5) spaded lugs and 100 ft tape measure.


### FALL-OF-POTENTIAL, STEP-TOUCH POTENTIAL



#### **4-POINT BONDING FOR VERY LOW RESISTANCE**

Ground Tester Control Panel File View Instrument Tools Wi     Go III III IIII IIII IIII IIII IIII		T (2000)	-	ST	X
Configuration			-		
Load From File	4W/ze Kalvin	~ «/- Auto Current	~		_
Save To File					
Set Instrument Clock Buzzer Disabled  Enabled C		DC 4-Wire Auto			
	Show H Input ()	Input Noise Show S Input ®			
	V S-ES = 0.00342V DC				

#### SOIL RESISTIVITY





Rev.00 05/2021

(2) 5 ft color-coded leads (red/blue),

# **GROUND RESISTANCE TESTERS** SELECTION CHART

AEMC Model Number	AEMC Catalog Number	RESISTANCE RANGE	POWER Source	2 Point Test	3 POINT TEST	4 Point/ Selective	SOIL Resistivity Test	EARTH Coupling	2 Clamp	BONDING	DISPLAY	VOLTAGE Indication	INDUCTANCE INDICATION	SWEEP Frequency		
6416	2141.01	0.01 to	Battery		w/Ala	ound Resista rm and Mem	lory	_	√ √**	Digital	Voltage	$\checkmark$	—			
6417	2141.02	1500Ω	Battery		w/Alar Bluetool	ound Resista m, Memory th communic	and cation		~	<b>√</b> **	Digital	Displayed (noise icon, buzzer)	$\checkmark$	_		
6418	2141.03	0.01 to 1200Ω	Battery	Clam		ound Resista rm and Mem		_	$\checkmark$	<b>√</b> **	Digital	Noise Icon	_	-		
6422	2135.55	0.05 to 50kΩ	Battery	$\checkmark$			_			$\checkmark$	Digital	Noise Icon	_			
6422 Kit 150FT	2135.56	0.05 to 50kΩ	Rechargeable Battery	$\checkmark$			_			$\checkmark$	Digital	Noise Icon				
6424	2135.57	0.05 to 50kΩ	Rechargeable Battery	$\checkmark$			_			$\checkmark$	Digital	Noise Icon	-	-		
6424 Kit 150FT	2135.58	0.05 to 50kΩ	Rechargeable Battery	$\checkmark$			_			$\checkmark$	Digital	Noise Icon	—			
6424 Kit 300FT	2135.59	0.05 to 50kΩ	Rechargeable Battery	$\checkmark$			_			$\checkmark$	Digital	Noise Icon	ise Icon —			
GroundFlex® Field Kit Model 6474	2136.03	0.001Ω to 99.99kΩ	Rechargeable Battery	_	- 🗸				_	$\checkmark$	Digital	Voltage Displayed	_	$\checkmark$		
6471 (SR182 probes not included)	2135.48	0.01 to 99.99kΩ	Rechargeable Battery		^	$\checkmark$			<b>√</b> ***	~	Digital	Voltage Displayed				
6471	2135.49	0.01 to 99.99kΩ	Rechargeable Battery			$\checkmark$			$\checkmark$	$\checkmark$	Digital	Voltage Displayed	_	-		
6471 Kit 300FT	2135.50	0.01 to 99.99kΩ	Rechargeable Battery			$\checkmark$			$\checkmark$	$\checkmark$	Digital	Voltage Displayed	-	-		
6472	2135.51	0.01 to 99.99kΩ	Rechargeable Battery			$\checkmark$			<b>√</b> ***	$\checkmark$	Digital	Voltage Displayed	v	/		
6472 Kit 300FT	2135.53	0.01 to 99.99kΩ	Rechargeable Battery			$\checkmark$			<b>√</b> ***	$\checkmark$	Digital	Voltage Displayed	v	/		
6472 Kit 500FT	2135.54	0.01 to 99.99kΩ	Rechargeable Battery			$\checkmark$			<b>√</b> ***	$\checkmark$	Digital	Voltage Displayed	v	/		
4620	2130.43	0.0 to 1999Ω	Battery	v	/	—	$\checkmark$		_		Digital	LED/Buzzer	-	-		
4620 Kit 150FT	2135.19	0.0 to 1999Ω	Battery	v	/	_	√*		_		Digital	LED/Buzzer	_	-		
4620 Kit 300FT	2135.20	0.0 to 1999Ω	Battery	v	/	_	$\checkmark$			_		LED/Buzzer —		-		
4620 Kit 500FT	2135.21	0.0 to 1999Ω	Battery	Ŷ	/	_	$\checkmark$		_		Digital	LED/Buzzer	—			
4630	2130.44	0.0 to 1999Ω	Rechargeable Battery	v	/ _		$\checkmark$		_		Digital	LED/Buzzer				
4630 Kit 150FT	2135.22	0.0 to 1999Ω	Rechargeable Battery	v	/ _		√*		_		_		Digital	LED/Buzzer	_	
4630 Kit 300FT	2135.23	0.0 to 1999Ω	Rechargeable Battery	٧	/	_		_			Digital	Digital LED/Buzzer		_		
4630 Kit 500FT	2135.24	0.0 to 1999Ω	Rechargeable Battery	v	/	_	$\checkmark$		_		Digital	LED/Buzzer		-		

\* Performing soil resistivity tests with this kit requires two additional auxiliary electrodes not supplied in the 150 ft kit and one additional test lead.

\*\* Clamp-on Ground Resistance Tester can measure system continuity inclusive of all bonding points.

\*\*\* Must purchase an additional (2) SR182 or (2) MN82 accessory clamps

